



1* IMPORTANT. Do not buy fake chinese VP230 ICs. Take care and use only verify originals Texas Instruments ICs.

2* Remove 120ohms SMD resistor or cut one of his trace on CAN bus transceiver.

3* Optional. VCC measure. R2 = R3 and any 10K to 50K at 1%

TITLE: CPX Interface		REV: 0.2
Company: SuSoDevs		Sheet: 1/1
Date: 2021-11-29		Drawn By: