





# The difference between the generated code file in the new SC version and the old version.

## 1. ADCA0

FileName	Function	New Version	Old Version	Note
Config_ADCA0.c	GetResult			-Change function in new version (add execution state of function).
	OperationOff			-Add new function.

## 2. General

FileName	Function	New Version	Old Version	Note
r_smc_interrupt.h		INTC_TAUD0_INTTAUD0I14_2_PRIORITY INTC_TAUD0_INTTAUD0I12_2_PRIORITY INTC_TAUD0_INTTAUD0I2_2_PRIORITY INTC_TAUD0_INTTAUD0I10_2_PRIORITY INTC_TAUD0_INTTAUD0I8_2_PRIORITY INTC_TAUD0_INTTAUD0I6_2_PRIORITY INTC_TAUD0_INTTAUD0I4_2_PRIORITY INTC_TAUD0_INTTAUD0I0_2_PRIORITY INTC_CSIG0_INTCSIG0IR_2_PRIORITY INTC_CSIG0_INTCSIG0IC_2_PRIORITY INTC_TAPA0_INTTAPA0IVLY0_2_PRIORITY INTC_TAPA0_INTTAPA0IPEK0_2_PRIORITY INTC_ADCA0_INTADCA0I2_2_PRIORITY INTC_CSIH1_INTCSIH1IJC_1_PRIORITY INTC_CSIH1_INTCSIH1IRE_1_PRIORITY INTC_CSIH1_INTCSIH1IR_1_PRIORITY INTC_CSIH1_INTCSIH1IC_1_PRIORITY INTC_CSIH3_INTCSIH3IJC_1_PRIORITY INTC_CSIH3_INTCSIH3IRE_1_PRIORITY INTC_CSIH3_INTCSIH3IR_1_PRIORITY INTC_CSIH2_INTCSIH2IJC_1_PRIORITY INTC_CSIH2_INTCSIH2IRE_1_PRIORITY INTC_CSIH2_INTCSIH2IR_1_PRIORITY INTC_CSIH3_INTCSIH3IC_1_PRIORITY INTC_CSIH2_INTCSIH2IC_1_PRIORITY		- Add some define.
r_cg_cgc.c				-Change Tab -> 4 blank character
r_cg_intvector.h				-Change Tab -> 4 blank character.

r_smc_interrupt.h	<pre> 10 #define INTC_PORT_INTP0_PRIORITY 11 #define INTC_PORT_INTP1_PRIORITY 12 #define INTC_PORT_INTP2_PRIORITY 13 #define INTC_PORT_INTP3_PRIORITY </pre>	<pre> 66 #define INTC_Port_INTP0_PRIORITY 67 #define INTC_Port_INTP1_PRIORITY 68 #define INTC_Port_INTP2_PRIORITY 69 #define INTC_Port_INTP3_PRIORITY </pre>	-Change lowercase ->upcase character of define.
r_cg_main.c	<pre> void R_MAIN_UserInit(void) {     ...DI();     .../* Start user code for R_MAIN_UserInit. Do not edit comment. */     .../* End user code. Do not edit comment generated here. */     ...R_Systeminit();     ...EI(); } </pre>	<pre> void r_main_userinit(void) {     ...DI();     .../* Start user code for r_main_userinit. Do not edit comment. */     .../* End user code. Do not edit comment generated here. */     ...R_Systeminit();     ...EI(); } </pre>	-Change lowercase ->upcase character of function.