

AIRBUS A340

FLIGHT CREW OPERATING MANUAL

NORMAL CHECK LIST

BEFORE START	
COCBIT PREP	COMPLETE
GEAR PINS and COVERS	REMOVED
SIGNS	ON
ADIRS	NAV
FUEL QUANTITY	KG
TO DATA	SET
BARO REF.	SET
WINDOWS/DOORS	CLOSED
BEACON	ON
THR LEVERS	IDLE
PARKING BRAKE	AS RORD
AFTER START	
ANTI ICE	AS RORD
ECAM STATUS	CHECKED
THR LEVERS	IDLE
PARKING BRAKE	AS RORD
BEFORE TAKEOFF	
FLIGHT CONTROLS	CHECKED
FLIGHT INST.	CHECKED
BRIEFING	CONFIRMED
FLAPS SETTING	CONF - SET
V1, VR, V2 / FLEX TEMP.	SET
ATC	SET
ECAM MEMO	TO ALL GREEN
• SIGNS ON • AUTO BRK MAX • CABIN READY • TO CONFIG NORM • SPLRS ARM • FLAPS TO	
CABIN CREW	ADVISED
ENG MODE SEL	AS RORD
PACKS	AS RORD
AFTER TAKEOFF / CLIMB	
LDG GEAR	UP
FLAPS	RETRACTED
PACKS	ON
BARO REF.	STD

APPROACH	
BRIEFING	CONFIRMED
ECAM STATUS	CHECKED
SEAT BELTS	ON
BARO REF.	SET
MDA / DH	SET
ENG MODE SEL	AS RORD
LANDING	
CABIN CREW	ADVISED
A/THR	SPEED / OFF
ECAM MEMO	LDG ALL GREEN
• SIGNS ON • FLAPS SET • CABIN READY • SPLRS ARM • LDG GEAR ON	
AFTER LANDING	
FLAPS	RETRACTED
SPOILERS	DISARMED
APU	START
PADAR	OFF / STBY
PARKING	
APU BLEED	ON
ENGINES	OFF
SEAT BELTS	OFF
EXT LT	AS RORD
FUEL PUMPS	OFF
PARKING BRAKE and CHOCKS	AS RORD
SECURING THE AIRCRAFT	
ADIRS	OFF
OXYGEN	OFF
APU BLEED	OFF
EMER EXIT LIGHTS	OFF
NO SMOKING	OFF
APU and BAT	OFF

ON GROUND EMER EVACUATION

- AIRCRAFT / PARKING BRK. STOP/ON
- ATC (VHF 1). NOTIFY
- ΔP (only if MAN CAB PR has been used). CHECK ZERO
if not zero, MODE SEL on MAN and V/S CTL FULL UP
- ENG MASTER 1 and 2. OFF
- CABIN CREW (PA). NOTIFY
- FIRE P/Bs (ENG and APU). PUSH
- AGENTS (ENG and APU). AS RORD
- EVACUATION. INITIATE

