

VE215 Introduction to Circuits

Sung-Liang Chen

Fall 2018



JOINT INSTITUTE
交大密西根学院

About me



- 1999 – 2003 B.S., Electrical Engineering National Taiwan University
- 2003 – 2005 M.S., Electro-optical Engineering, National Taiwan University
- 2007.09 – 2011.12 Ph.D., Electrical Engineering, University of Michigan
- 2012.01 – 2013.03 Research Fellow, Radiology Department, University of Michigan
- 2013.05 – present Assistant Professor, UM-SJTU Joint Institute, Shanghai Jiao Tong University

What are circuits?


Circuit–Merriam Webster's definition

- **a** : the complete path of an electric current including usually the source of electric energy
- **b** : an assemblage of electronic elements
- **c** : a two-way communication path between points (as in a computer)
- **d** : a neuronal pathway of the brain along which electrical and chemical signals travel




Circuit–Wikipedia's definition (part list)

- Circuit theory, the theory of accomplishing work by routing **electrons, gas, fluids, or other matter** through loops
- In **electrical engineering**
 - Electrical circuit
- In **fluid power** and **fluid mechanics**
 - Hydraulic circuit
 - Pneumatic circuit
- In **physics**
 - Magnetic circuit
- In **mathematics and computer science...**
- ...




Circuit – Electrical Engineering

- In electrical engineering
 - Circuit analysis: V and I
 - Series and parallel circuits
 - LC circuit
 - Analog circuit or digital circuit
 - Integrated circuit
 - Mixed-signal integrated circuit



Electrical circuit


- An **electrical circuit** is a **path** in which **electrons** from a voltage or current source **flow**.
- Electric current flows in a **closed path**.
- A simple electrical circuit
 - A power source
 - A complete path for electrons to flow
 - A resistor as the load



Electrical circuits and electronic circuits

■ Electrical circuits

- Usually alternating current sources
- Load: refrigerators, televisions, or microwave ovens; the output of a **hydroelectric power** generating station.



■ Electronic circuits


- Usually low voltage direct current sources
- Load: the flash in a digital camera; the microprocessors.

More on electronic circuit

- Definition: An electronic circuit is composed of **individual electronic components**, such as resistors, transistors, capacitors, inductors and diodes, connected by conductive wires or traces through which electric current can flow.
- Function: The combination of components and wires allows various simple and complex operations to be performed:
 - signals can be amplified
 - computations can be performed
 - data can be moved from one place to another

Print circuit board (PCB)

- Circuits can be constructed of discrete components connected by individual pieces of wire.
- Today it is much more common to create interconnections **by photolithographic techniques** on a laminated substrate (a printed circuit board or PCB) and solder the components to these interconnections to create a finished circuit.




Markings on PCB

| | | | |
|----------------|------------------------------------|-------------------------|--------------------------------------|
| A | separable assembly | LS | loudspeaker, buzzer |
| AR | amplifier | M | meter |
| AT | attenuator; isolator | MG | motor-generator |
| B | blower, motor | MH* | mounting hole |
| BT | battery | MK | microphone |
| C | capacitor | MP | mechanical part |
| CB | circuit breaker | P | connector, plug, male |
| CP | connector adapter, coupling | PS | power supply |
| CN | capacitor network | Q | transistor |
| D or CR | diode | R | resistor |
| D or VR | breakdown diode | RN | resistor network |
| DC | directional coupler | RT | thermistor |
| DL | delay line | S | switch |
| DS | display, lamp | T | transformer |
| E | terminal | TB | terminal board, terminal strip |
| F | fuse | TC | thermocouple |
| FD* | fiducial | TP⁻⁻⁻ | test point, In-circuit test points |
| FL | filter | TZ | transzorb |
| G | generator, oscillator | U | inseparable assembly, IC pkg |
| GN | general network | V | electron tube |
| H | hardware | VR | voltage regulator |
| HY | circulator, directional coupler | W | wire, cable, cable assembly |
| J | connector, jack, female | X | fuse holder, lamp holder, socket |
| K | contactor, relay | Y | crystal, magnetostriction oscillator |
| L | coil, inductor, bead, ferrite bead | Z | miscellaneous |

Integrated circuit (IC)

In an IC, the components and interconnections are formed on the same substrate, typically a semiconductor such as silicon or (less commonly) gallium arsenide.



The die from an Intel 8742, an **8-bit microcontroller** that includes


- a CPU
- 128 bytes of RAM
- 2048 bytes of EPROM
- I/O

Categories of electronic circuit

- Analog circuits
- Digital circuits
- Mixed-signal circuits (a combination of analog circuits and digital circuits)


Analog circuits

- Current or voltage may **vary continuously** with time to correspond to the information being represented.




An analog circuit (a simple amplifier)


- Distributed*



Lumped



Lumped



Applicability/Validity

- The lumped element model ($L_c \ll \lambda$):
 - Ignores the finite time it takes signals to propagate around a circuit.
 - The attributes of the circuit elements are **concentrated into idealized electrical components** (resistors, capacitors, and inductors, etc.) joined by a network of **perfectly conducting wires**.
- Distributed circuit model ($L_c \sim \lambda$):
 - When the circuit size is comparable to a wavelength of the relevant signal frequency.
 - Such considerations typically become important for circuit boards at frequencies above a GHz.

L_c : circuit's characteristic length; λ : circuit's operating wavelength


Digital circuits

- Electric signals take on **discrete values**, to represent logical and numeric values.
- In the vast majority of cases, **binary encoding** is used: one voltage (typically the more positive value) represents a binary '1' and another voltage (usually a value near the ground potential, 0 V) represents a binary '0'.
- Extensive use of transistors, interconnected to create logic gates that **provide the functions of Boolean logic**: AND, NAND, OR, NOR, XOR and all possible combinations thereof.

Digital circuits

- Advantages over analog circuits
 - Each logic gate regenerates the binary signal, so the designer **need not account for distortion, gain control, offset voltages, and other concerns** faced in an analog design.
 - Extremely **complex digital circuits** (billions of logic elements integrated on a single silicon chip) can be fabricated **at low cost**.
- Digital circuitry
 - General purpose computing chips, such as microprocessors
 - Custom-designed logic circuits, known as application-specific integrated circuit (ASICs).
 - Field-programmable gate arrays (FPGAs), chips with logic circuitry whose configuration can be modified after fabrication
- Applications
 - Ubiquitous in modern electronic devices

Digital circuits-microprocessor



Intel 80486DX2
microprocessor

Digital circuits-FPGA




FPGA from Altera



FPGA from Xilinx

Sequential digital logic (example)














































- Different results for $P \rightarrow Q$ (towards right) and $Q \rightarrow P$ (towards left)
- Car hits P line: P turned to 1; Car hits Q line: Q turned to 1
- Electrical line colors: A **high (1)** signal is shown in **red** and a **low (0)** signal is shown in **green**
- Whilst you are looking at the animation try to follow the signals propagating through the circuit using the rules for the gates (NOT and NAND here).
- Results:
 - $P=1 \rightarrow Q=1$, output light becomes red.
 - $Q=1 \rightarrow P=1$, output light keeps green.

Mixed-signal circuits

- Mixed-signal or hybrid circuits contain elements of both analog and digital circuits.
- Examples: Comparators, timers, phase-locked loops, analog-to-digital converters, and digital-to-analog converters (E.g., A laser marking machine).
- Most modern radio and communications circuitry uses mixed signal circuits. E.g, in a receiver:
 - Analog: amplification, frequency conversion
 - Digital: signal processing



Circuit symbols-passive components


| | | | | |
|---|---|---|---|---|
| Resistor | Variable Resistor | Preset | Thermistor | |
|  |  |  |  | |
| <hr/> | | | | |
| Capacitor | Electrolytic Capacitor | Variable | Trimmer | Ganged Variable Capacitors |
|  |  |  |  |  |
| <hr/> | | | | |
| Air Wound Coils | Iron Core | Dust Core | Preset | Variable Inductor |
|  |  |  |  |  |
| <hr/> | | | | |
| Transformer | Centre Tapped Transformer | IFT | Variable IFT | |
|  |  |  |  | |
| <hr/> | | | | |
| Dynamic MIC | ECM MIC | Loudspeaker | Piezo | Crystal |
|  |  |  |  |  |
| <hr/> | | | | |
| Indicator Lamps | | Motor | Voltmeter | Terminal or Test Point |
|  |  |  |  |  |
| <hr/> | | | | |
| Battery | Relay | Alternative Relay Contacts | Fuse | Stereo Jack |
|  |  |  |  |  |
| <hr/> | | | | |
| Switch | SPDT Switch | Rotary Switch | Push Button Switch | NC PBS |
|  |  |  |  |  |
| <hr/> | | | | |
| Aerial | Earth | Chassis | Wires (Joined) | (Not Joined) |
|  |  |  |  |  |

Circuit symbols-active components

| | | | |
|--------------------------|--------|--------------------------|--------------------|
| Diode | Triode | Tetrode | Pentode |
| | | | |
| Transistors | | Unijunction Transistor | Double Gate MOSFET |
| | | | |
| Field Effect Transistors | | Darlington Transistors | |
| | | | |
| MOSFETS Depletion Mode | | MOSFETS Enhancement Mode | |
| | | | |
| Schottky Diode | Diac | Triac | SCR |
| | | | |
| Diode | LED | Zener | Varactor |
| | | | |


Example-operational amplifier

- Widely used in signal processing circuits, control circuits, and instrumentation
- An operational amplifier (op-amp) is a high gain, differential, voltage amplifier.
 - Voltage amplifier: the input is a voltage and the output is a voltage.
 - Typically, the gain is over 100,000
 - Differential amplifier: It actually amplifies the difference between two voltages.
- Symbol
 - V_{out} is the output voltage
 - V_+ is the non-inverting input voltage
 - V_- is the inverting input voltage




Example-operational amplifier

- The 741, a typical op-amp




A typical op-amp on a circuit board



- Most op-amps today are ICs. Of course the actual size is smaller than the picture above!


Example-operational amplifier



A component-level diagram of the common 741 op-amp. Dotted lines outline: current mirrors (red); differential amplifier (blue); class A gain stage (magenta); voltage level shifter (green); output stage (cyan).


Example-a photodetector

- New Focus™ 1801



Example-a photodetector


- New Focus™ 1801-AC





Example-a photodetector

Optical signal input



Electrical signal output



By 1801





By 1801-AC




Application: Fiber-optic hydrophone

- Advantage: to amplify and extract **only** the small modulated signal (the useful signal)






Circuit types




Circuit types



Electrical
Circuits




Magnetic
Circuits




Mechanical
Circuits

Bio
Circuits



Circuit hierarchy



Circuit related curriculum in JI

Freshmen

- Math
- Physics
- Programming

Sophomore

- **VE215**
Introduction to Circuits
- **VE216**
Signal and System
- **VE230**
Electromagnetics
- **VE270**
Introduction to Logic Design

Junior

- **VE311**
Analog circuits
- **VE320**
Semiconductor
- **VE330**
Electromagnetics II
- **VE312**
Digital Integrated Circuits
- **VE334**
Optics

Senior

- **VE413**
Analog IC
- **VE411**
RF Microwave Circuits
- **VE427**
VLSI I
- **VE434**
Photonics

My contact

- Office location:

Rm. 428, JI Building

- Office tel:

3420-6045 ext. 4281

- Email:


sungliang.chen@sjtu.edu.cn

Course expectation and requirement


- Pre-requisites: VV156 or VV186, VG101
- Co-requisites: VP240 or VP260
- Basic college math and physics
 - Scalar & Vector
 - Differentiation & Integration
 - Electric Charge
 - Current & Voltage

Textbook


Main Textbook



Laboratory book



Computer Aided Design - CAD



- Pspice CAD tool to simulate most analog and digital circuits.
- Demo version available online for free.

<http://www.cadence.com/products/orcad/pages/downloads.aspx#demo>

Course schedule

- Lectures:

- Monday 8:00 – 9:40 am
- Wednesday 4:00 – 5:40 pm
- Friday 10:00 – 11:40 am (weeks 1–5)

- Recitation: TBD

- My office hours: Tu & We 2:00 – 3:00 pm

- TA office hours: TBD

Teaching assistants (TAs)

- Yuanhao Wang (王袁皓)
wangyuanhao980405@sjtu.edu.cn
- Yan Fang (方砚)
fangyan1998@sjtu.edu.cn
- Runqing Zhou (周润卿)
zrq16sjtu@sjtu.edu.cn

Grading policy

- In-class Quizzes 5%
- Homework 15%
 - 10 problem sets
- Lab 15%
 - 5 labs
- Midterm 1 20%
- Midterm 2 20%
- Final 25%

The JI Honor Code

- Personal integrity as students and professionals.
- Respect other people and their work.
- Respect yourself and your own efforts.
- Mutual trust.
- Applicable to all your academic activities here, including homework, quizzes, lab reports, projects and exams.
- Violations will be reported to the Honor Council.
 - Copy other student's homework, quizzes, lab reports, exams.
 - Illegal copy of online resource and academic literatures.
 - Helping others on the abovementioned activities.
 - Fake ID for exams.

Class rules

- Please do not come in late and do not get up to leave until the class is dismissed.
- You are responsible for all material covered in class, whether or not it is in the book.

Homework rules

- Homework will be assigned online at Canvas as scheduled. They are usually due one week later or specified otherwise. **One day automatic grace period; second day late penalty -25%; later no credit.**
- Students should complete the homework independently. Copy of others' homework is not allowed and is a violation to the Honor Code.
- Solutions will be posted on Sakai one week after the due date.

Exam rules

- There will be two midterm exams and one final exam. Each lasts 100 minutes.
- Students should complete the exam independently. No talk and collaboration are allowed.
- Closed book, cheat sheet may be allowed.
- No electronic devices except basic calculators will be allowed to use.

| Week | Date | Lecture Topics | Homework | Labs |
|------|--------|---|-------------|------|
| 1 | Sep 10 | Introduction to Ve215, Basic concepts (Sections 1.3-1.7) | | |
| | Sep 12 | Basic laws (2.1-2.8) | HW1 issued | |
| | Sep 14 | Methods of analysis (3.1-3.6) | | |
| 2 | Sep 17 | Methods of analysis (3.7,3.9), Circuit theorems (4.1-4.4) | HW2 issued | |
| | Sep 19 | Circuit theorems (4.5-4.8, 4.10) | | |
| | Sep 21 | Operational amplifiers (5.1-5.5) | HW3 issued | |
| 3 | Sep 24 | Moon Festival | | |
| | Sep 26 | Operational amplifiers (5.6-5.8, 5.10) | | |
| | Sep 28 | Capacitors and inductors (6.1-6.6) | HW4 issued | |
| 4 | Oct 1 | No lecture, National Holiday | | |
| | Oct 3 | No lecture, National Holiday | | |
| | Oct 5 | No lecture, National Holiday | | |
| 5 | Oct 8 | No lecture, Midterm Exam 1 | | Lab1 |
| | Oct 10 | First-order circuits (7.1-7.4) | | |
| | Oct 12 | First-order circuits (7.5-7.7, 7.9) | HW5 issued | |
| 6 | Oct 15 | Second-order circuits (8.1-8.6) | | Lab2 |
| | Oct 17 | Second-order circuits (8.7-8.8, 8.10-8.11) | | |
| 7 | Oct 22 | Sinusoids and phasors (9.1-9.4) | HW6 issued | Lab3 |
| | Oct 24 | Sinusoids and phasors (9.5-9.8) | | |
| 8 | Oct 29 | Sinusoidal steady-state analysis (10.1-10.6) | | Lab4 |
| | Oct 31 | Sinusoidal steady-state analysis (10.7, 10.9) | HW7 issued | |
| 9 | Nov 5 | No lecture, Midterm Exam 2 | | Lab5 |
| | Nov 7 | AC power analysis (11.1-11.6) | | |
| 10 | Nov 12 | AC power analysis (11.7-11.9) | | |
| | Nov 14 | Three-phase circuits (12.1-12.6) | | |
| 11 | Nov 19 | Three-phase circuits (12.7-12.8, 12.10) | HW8 issued | |
| | Nov 21 | Magnetically coupled circuits (13.1-13.5) | | |
| 12 | Nov 26 | Magnetically coupled circuits (13.6-13.7, 13.9) | HW9 issued | |
| | Nov 28 | Frequency response (14.1-14.3) | | |
| 13 | Dec 3 | Frequency response (14.4-14.6) | HW10 issued | |
| | Dec 5 | Frequency response (14.7-14.8) | | |
| 14 | Dec 10 | No lecture, Final Exam | | |

Any questions?