

Product Data

Cytotoxic Drug Spill Station

Cairn Technology's Cytotoxic Drug Spill Station has been carefully developed over a number of years. We have drawn on the experience of professionals working with chemo-therapy drugs in major NHS Trusts as well as our own expertise in the management of incidents involving uncontrolled releases of hazardous materials.

The Cytotoxic Drug Spill Station is available in two formats:

- **Fixed – wall-mounted base station;**
- **Portable QuickBag**

The Fixed Base Station & Portable QuickBag

The **fixed base station** is made up of:

- A base unit consisting of a top compartment with drug safety information and spill procedure forms
- 2 removable one shot QuickBags with PPE & cleanup/waste disposal equipment
- A removable Extras QuickBag with additional equipment for dealing with a larger spill (i.e. over 1 litre)

The **one shot QuickBags** are available individually as a portable option and contain all the equipment required to manage a spill.



The base station and QuickBags have a low profile design for space efficiency and have been manufactured from fire-resistant, anti-fungal, anti-bacterial wipe-clean material.

The entire contents of the QuickBag, including the outer are designed to be disposed of once used.

Product Data

Contents

A standard QuickBag contains the following PPE & clean-up/waste disposal equipment.
The fixed base station contains two standard QuickBags plus an Extras Quickbag.

Personal Protective Equipment:

Two individually packed sets of PPE, each containing:

- 1 Microguard 2500 laboratory coat (white)
- 1 pair Microguard 2500 sleeves (white)
- 1 pair Microguard 2500 overshoes (white)
- 1 pair eyeshields – with side shields to protect against splashes and aerosols
- 2 pairs (double glove) – specialist cyto-gloves
- 1 Moldex facepiece – to protect against splashes and aerosols (not meant as a fume or vapour filter)



Clean-up/Waste Disposal Equipment:

Equipment to **absorb drug safely**:

- 1 SLIPPA (blue/white) - super-absorbing polymer gels up to 1 litre of liquid

Equipment for **three-stage clean-up** procedure:

- 1 protective floor/kneeling mat
- 3 sterile water twist-cap bottles (20 ml)
- 9 wipes - lint free
- 3 absorbent pads (grey)
- 1 pair plastic tweezers

Equipment for **waste disposal** procedure:

- 1 'Special Waste' bag and tie
- 1 batch number label
- 1 laminated warning sign
- 1 cytotoxic spill emergency procedure

The Extras QuickBag

This contains additional equipment that is only required for spills of larger volume or for spills that have escaped, or been transferred, over a wide area:

- 3 SLIPPAS (blue/white) – super-absorbing polymer gels up to 3 litres of liquid
- 3 absorbent pads (grey)
- 9 wipes – lint free
- 1 Microguard 2500 coverall (white)

For more information about this and other products, or to place an order, please call us on 0114 244 9551.

