

C++ IO support for various FEM exchange file formats

Berthold Höllmann

November 1, 2017

Contents

1	Supported FEM file formats	1
1.1	Unit system considerations	1
1.2	NASTRAN Bulk Data Format (BDF)	1
1.2.1	BDF Cards supported	1
1.2.1.1	Bulk Data	1
1.2.1.2	Header Data	2
1.3	DNV GL Seasam Input Interface File (FEM)	3
1.3.1	FEM Cards supported	3
1.3.2	Element Types in SESAM	4

1 Supported FEM file formats

Not all functionality defined for the exchange file formats is supported. The supported subset is currently mainly defined by the functionality supported in GLFrame rspt. the BMF file format.

More detailed information on supported functionality can be found in the according directories in the docs subdirectory.

1.1 Unit system considerations

Unit systems used by the different systems are:

Dimension \ System	Poseidon	Nastran	Sesam / GeniE
L (Length Unit)	[m] for nodes [mm] for plate thicknesses	[m]	[m]
M (Mass Unit)	[t]	[t]	[t]
ML/T ² Force Unit)	[kN]	[kN]	[kN]

Yield stress is stored in [kN/m²] in Sesam / GeniE, but [N/mm²] in POSEIDON.

1.2 NASTRAN Bulk Data Format (BDF)

1.2.1 BDF Cards supported

1.2.1.1 Bulk Data

	Name	Description	Read	Write
General	MAT1	Material definition	✓	✓
	MAT2	Shell Element Anisotropic Material Property Definition	✓	✓
	GRID	Grid nodes	✓	✓
Elements	CTRIA3	3 node shaped shell elements	✓	✓
	CQUAD4	4 node shaped shell elements	✓	✓
	CBEAM	Complex beams ¹	✓	✓
	CBAR	Simple beams	✓	✓
	CROD	Trusses	✓	✓
	CBUSH	Generalized Spring-and-Damper Connection	✗	✓
Element properties	PSHELL	Properties for CTRIA3, and CQUAD4	✓	✓
	PBEAM	Integral properties for CBEAM	✓	✓
	PBEAML	Properties for CBEAM describing cross section	✓	✓
	PBAR	Integral properties for CBAR	✓	✓
	PBARL	Properties for CBAR describing cross section	✓	✓
	PROD	Properties for CROD	✓	✓
	PBUSH	Generalized Spring-and-Damper Property	✗	✓
Load	LOAD	Load case combination	✓	✓
	FORCE	Forces on Nodes	✓	✓
	MOMENT	Moments on Nodes	✓	✓
	CONM1	Concentrated Mass Element Connection, General Form	✗	✓
	CMASS2	Scalar Mass Property and Connection	✓	✗
	CMASS4	Scalar Mass Property and Connection to Scalar Points Only	✓	✗
	GRAV	Acceleration or Gravity Load	✓	✓
Misc	ENDDATA	Marker for end of input file	✓	✓
	PARAM	Specifies values for parameters used in solution sequences or user written DMAP programs.	✓	✓

1.2.1.2 Header Data

Name	Description	Read	Write
SOL	Execute a Solution Sequence	✗	✓
CEND	End of Executive Control Delimiter	✗	✓
TITLE	Output Title	✗	✓
ECHO	Bulk Data Echo Request	✗	✓
DISPLACEMENT	Displacement Output Request	✗	✓
SPCFORCES	Single-Point Forces of Constraint Output Request	✗	✓
STRESS	Element Stress Output Request	✗	✓
LOAD	External Static Load Set Selection	✗	✓
SUBTITLE	Output Subtitle	✗	✓
SUBCASE	Subcase Delimiter	✗	✓
BEGIN BULK	Case Control and Bulk Data Delimiter	✗	✓

¹Twisting CBEAM cross section by using the BIT flag is not supported. Offset via OFFT is only supported for the same offset at A and B end of beam.

1.3 DNV GL Seasm Input Interface File (FEM)

1.3.1 FEM Cards supported

	Name	Description	Read	Write	Page ²
General					
	DATE	Date and Program Information	✓	✓	4-2
	GCOORD	Nodal Coordinates	✓	✓	6-56
	GNODE	Correspondence between External and Internal Node Numbering, and Number of Degrees of Freedom of Each Node	✓	✓	6-80
	IDENT	Identification of Superelements	✓	✓	4-3
	IEND	End of a Superelement	✓	✓	4-4
Elements					
	GELMNT1	Element Data Definition	✓	✓	6-65
	GELREF1	Reference to Element Data	✓	✓	6-66
Element properties					
	GBEAMG	General Beam Element Data	✓	✓	6-49
	GBARM	Cross Section Type Massive Bar	✓	✓	6-48
	GIORH	Cross Section Type I or H Beam	✓	✓	6-71
	GLSEC	Cross Section Type L-Section	✓	✓	6-76
	GPIPE	Cross Section Type Tube	✓	✓	6-81
	GUSYI	Cross Section Type Unsymmetrical I-Beam	✓	✓	6-93
	GECCEN	Eccentricities	✓	✓	6-61
	BELFIX	Flexible Joint/Hinge	✓	✓	6-8
	GELTH	Thickness of Two-dimensional Elements	✓	✓	6-70
Load					
	BLDEP	Nodes with Linear Dependence	✓	✓	6-27
	BNBCD	Nodes with Boundary Conditions	✓	✓	6-30
	BNDISPL	Nodes with Prescribed Displacements and Accelerations	✓	✓	6-31
	BNLOAD	Nodes with Loads	✓	✓	6-35
	MGSPRNG	Element to Ground	✓	✓	6-103
	TDLOAD	not documented (Seems to be similar to TD-MATER or TDSETNAM)	✓	✓	
	BEUSLO	Elements with Surface Loads	✓	✓	6-21
Superel.					
	BSELL	Subelement Load Description	✓	✓	7-27
	GELMNT2	Subelement Description with Simple Correspondence	✓	✓	7-31
	HSUPSTAT	Superelement Statistical Information	✓	✓	7-40
	HSUPTRAN	Superelement Transformations	✓	✓	7-41
	HIERARCH	Superelement Hierarchy Description	✓	✓	7-38
	TDSUPNAM	Name and Description of a Super-Element.	✓	✓	4-8
Misc					
	GSETMEMB	Set (group) of Nodes or Elements (Members)	✓	✓	6-84
	GUNIVEC	Specification of Local Element Coordinate System	✓	✓	6-92
	MISOSEL	Isotropy, Linear Elastic Structural Analysis	✓	✓	6-115
	MORSMEL	Anisotropy, Linear Elastic Structural Analysis, 2-D Membrane Elements and 2-D Thin Shell Elements	✓	✓	6-117
	TDSETNAM	Name and Description of a Set (group)	✓	✓	4-7
	TEXT	User supplied Text	✓	✓	4-10

1.3.2 Element Types in SESAM

Conventions for use of the interface file for the elements in SESAM are defined here. Other element types may be introduced for use in other programs.

The table below contains element type numbers already reserved. (Not all of them are included in SESAM).

For ADVANCE, the element types listed are those available from the SESAM preprocessors. In addition to that ADVANCE has a lot of other element types.

Table 1: List of existing Element Types

Typ ³	Name	N. ⁴	Description of Element	Ref.	5	6	7	8	9	Other ¹⁰
1			<i>Not yet defined</i>							
2	BEPS	2	2-D, 2 Node Beam	3, 5	✓			✓		
3	CSTA	3	Plane Constant Strain Triangle	2, 4		✓	✓	✓		
4			<i>Not yet defined</i>	3						
5	RPBQ	4	Rectangular Plate. Bending Modes	3						
6	ILST	6	Plane Lin. Strain Triangle	2		✓	✓			
7			<i>Not yet defined</i>							
8	IQQE	8	Plane Quadrilateral Membrane Element	2		✓	✓			
9	LQUA	4	Plane Quadrilateral Membrane Element	2, 4		✓	✓	✓		
10	TESS	2	Truss Element	2, 4	✓	✓	✓	✓	✓	
11	GMAS	1	1-Noded Mass-Matrix			✓	✓		✗	
12	GLMA	2	2-Noded Mass-Matrix				✓			
13	GLDA	2	2-Noded Damping-Matrix							
14			<i>Not yet defined</i>							
15	BEAS	2	3-D, 2 Node Beam	2, 4	✓	✓	✓	✓	✓	FR, LA, PL, PR, WA
16	AXIS	2	Axial Spring		✓	✓	✓	✓ ¹⁹	✗	FR
17	AXDA	2	Axial Damper		✓	✓	✓		✗	
18	GSPR	1	Spring to Ground	4	✓	✓	✓	✓	✗	FR
19	GDAM	1	Damper to Ground		✓	✓	✓		✗	
20	IHEX	20	Isoparametric Hexahedron	2		✓	✓	✓		FR
21	LHEX	8	Linear Hexahedron	2, 4		✓	✓	✓		FR
22	SECB	3	Subparametric Curved Beam	2						
23	BTSS	3	General Curved Beam	2		✓	✓			PL, PR
24	FQUS	4	Flat Quadrilateral Thin Shell	4		✓	✓		✓	PL, PR
24	FFQ	4	Free Formulation Quadrilateral Shell	5				✓		
25	FTRS	3	Flat Triangular Thin Shell	4		✓	✓		✓	PL
25	FFTR	3	Free Formulation Triangular Shell	5				✓		
26	SCTS	6	Subparametric Curved Triangular Thick Shell	2		✓	✓			PL
27	MCTS	6	Subparametric Curved Triangular Thick Sandwich Element	2 ²⁰		✓	✓			

Continued on next page

²References page in "Technical Report: Sesam Input Interface File, File Description", Document id: 89-7012, Revision Number 9 / 01

Continued from previous page

Typ ¹¹	Name	N. ¹²	Description of Element	Ref.	13	14	15	16	17	Other ¹⁸
28	SCQS	8	Subparametric Curved Quadrilateral Thick Shell	2		✓	✓			PL, PR
29	MCQS	8	Subparam. Curved Quadr. Thick Sandwich Elem.	2 ¹²		✓	✓			
30	IPRI	15	Isoparametric Triangular Prism	2		✓	✓	✓		
31	ITET	10	Isoparametric Tetrahedron	2			✓			
32	TPRI	6	Triangular Prism	2, 4		✓	✓	✓		
33	TETR	4	Tetrahedron	2			✓			
34	LCTS	6	Subparam. Layered Curved Triangular Thick Shell	2 ¹²		✓	✓			
35	LCQS	8	Subparam. Layered Curved Quadrilat. Thick Shell	2 ¹²		✓	✓			
36	TRS1	18	2nd Order Hexahed. Transi- tion Elem., Solid / Shell	6			✓			PR
37	TRS2	15	2nd Order Hexahed. Transi- tion Elem., Solid / Shell	6			✓			PR
38	TRS3	12	2nd Order Hexahed. Transi- tion Elem., Solid / Shell	6			✓			PR
39			<i>Not yet defined</i>							
40	GLSH	2	General Spring / Shim Ele- ment	21	✓		✓		✗	
41	AXCS	3	Axisymmetric Constant Strain Triangle	7, 5		✓	✓	✓		
42	AXLQ	4	Axisymmetric Quadrilateral	7, 5		✓	✓	✓		
43	AXLS	6	Axisymmetric Linear Strain Triangle	7		✓	✓			
44	AXQQ	8	Axisymmetric Linear Strain Quadrilateral	7		✓	✓			
45	PILS	1	Pile / Soil	4	✓			✓		
46	PCAB	2	Plane Cable-Bar Element	4	✓			✓		
47	PSPR	1	Plane Spring Element	4	✓			✓		
48		4	4-node Contact Element with triangular Shape	4				✓		
49		2	2-Noded Link Element	4				✓		
50			<i>Not yet defined</i>							
51	CTCP	2	2-Noded Contact Element							
52	CTCL	4	4-Noded Contact Element							
53	CTAL	4	4-Noded Axisymmetric Con- tact Element							
54	CTCC	6	6-Noded Contact Element							
55	CTAQ	6	6-Noded (3+3) Axisymmetric Contact Element			✓				
56	CTLQ	8	8-Noded (4+4) Contact Ele- ment	8, 9						PR
57	CTCQ	16	16-Noded (8+8) Contact Ele- ment	8, 9		✓				PR
58	CTMQ	18	18-Noded (9+9) Contact Ele- ment	8, 9						PR
59			<i>Not yet defined</i>							
60			<i>Not yet defined</i>							
61	HCQS	9	9-Noded Shell Element			✓				PR
62			<i>Not yet defined</i>							

Continued on next page

Continued from previous page

Typ ¹¹	Name	N. ¹²	Description of Element	Ref.	13	14	15	16	17	Other ¹⁸
63			<i>Not yet defined</i>							
64			<i>Not yet defined</i>							
65			<i>Not yet defined</i>							
66	SLQS	8	Semiloof Quadrilateral Curved Thin Shell (32 d.o.fs)							
67	SLTS	6	Semiloof Triangular Curved Thin Shell (24 d.o.fs)							
68	SLCB	3	Semiloof Curved Beam (11 d.o.fs)							
69			<i>Not yet defined</i>							
70	MATR	<i>n</i>	General Matrix Element with arbitrary no. of nodes (<i>n</i>)					✓		SP
...										
100	GHEX	21	General Hexahedron				✓			
...										
163	GHEX	27	General Hexahedron				✓			

³ELTYP

⁴Number of nodes

⁵Included in program PREFRAME

⁶Included in program PREFEM

⁷Included in program SESTRA

⁸Included in program ADVANCE

⁹Included in program Poseidon

¹⁰**FR** = FRAMEWORK, **LA** = LAUNCH, **PL** = PLATEWORK, **PR** = PRETUBE, **SP** = SPLICE, **WD** = WADAM, **WJ** = WAJAC

¹¹Temporarily ADVANCE interprets Axisl Spring as link element, ignoring the material reference. The 6 matrix numbers are given in direct input to ADVANCE.

¹²The element subroutines are the same as for the subparametric curved thick shells (SCQS and SCTS).

¹³As General Spring it is just a 2-noded spring (12x12 matrix) which may be in a local coordinate system. As a shim element the preprocessor(s) will only insert stiffness in the local x- and y-direction. In the analysis program(s), shim members and general springs are treated exactly in the same manner.