


## INSTALLATION INSTRUCTIONS

**Confidential : A**

**SKU: VA3621V8WH**

**PROHIBIT COPY**

- Prior to installation please check received items against the Packing List .If any part is missing or damaged, please do not return the product to the store and contact us;  
Call: (302)336-8180  
Email: vanityinservice@gmail.com
- Protect all surfaces from sharp objects , high heat sources,direct prolonged sunlight and chemical hazards .
- Professional installation is recommended !



## INSTALLATION INSTRUCTIONS


**Confidentialal : A**

**SKU: VA3621V8WH**

**PROHIBIT COPY**

### NOTE

1. Ceramic sink: cUPC certified.



2. LED light :

a. The LED light is replaceable, if it is damaged, please contact us ;

Call: (302)336-8180


Email: [vanityinservice@gmail.com](mailto:vanityinservice@gmail.com)

b. LED light should be connected to the wall switch for turning on/off.


c. UL certified & IP67 for water proof.



Marble top with ceramic sink




Vanity



LED light

( pre-assembled on the bottom of the vanity )

wall switch



## INSTALLATION INSTRUCTIONS


**SKU: VA3621V8WH**

**Confidential : A**


**PROHIBIT COPY**

## PACKING LIST


**A Main Vanity**  
1 PC




**B Wood Cleat**  
1 PC




**C Metal Bracket**  
2 PCS




**D TOP**  
1 PC



**E Wood Screw**  
4 PCS



**F Wood Screw**  
8 PCS




M5 x 50

**G Wood Screw**  
4 PCS




M4 x 15

**H Wall Anchor**  
12 PCS



**I Metal Washers**  
4 PCS




## TOOLS REQUIRED


**Drill Bits**




**Screw Driver**




**Drill**



**Level**



**Knife**



**Glove**




**MASONRY DRILL BIT FOR  
TILE Ø3/8" (8mm)**



**Safety Glasses**



**Silicone**



**Measuring Tape**



**Soft Head  
Hammer**



**Pencil**



**Wood stud finder**



INSTALLATION INSTRUCTIONS

SKU: VA3621V8WH

Confidentialal : A


PROHIBIT COPY

- STEP 1:
- Use a wood stud finder to locate the wood studs behind the walls.
  - Use a pencil to mark the installation location for the **Wood Cleat (B)**.
  - Use a level to ensure the **Wood Cleat (B)** will be level before installing to the wall.


NOTE

Make sure the screw holes must be on the wood studs otherwise the vanity will fall out because the dry wall cannot hold the cabinet.

vanity	hole	a	b	c
36"	3	12"	12"	-
48"	4	12"	12"	12"
60"	4	12"	24"	12"




- STEP 2: Drill the anchor holes according to the marks using a drill.



INSTALLATION INSTRUCTIONS

SKU: VA3621V8WH


STEP 3: Install the **Wall Anchors (H)** provided into the wall with hammer.



Confidentialal : A


PROHIBIT COPY

STEP 4: Install the **Wood cleat (B)** to the wood studs by screw driver.




STEP 5: With help from another person, carefully hang the **Vanity (A)** onto the **Wood Cleat (B)**.

NOTE When installing the **Wood Cleat (B)** make sure the angle cut is facing the wall.



STEP 6: Using a pencil to mark the installation location for the **Metal Brackets (C)**.

NOTE Make sure the **Metal Brackets (C)** are installed on the wood studs.




## INSTALLATION INSTRUCTIONS

**SKU: VA3621V8WH**

**STEP 7:** Carefully remove the **Vanity (A)** with the help from another person, and then drill the anchor holes according to the marks using a drill.


Anchor Hole  
dia=  $\varnothing 3/8"$  (8mm)  
Depth=3.2"



**Confidential : A**


**PROHIBIT COPY**

**STEP 8:** Install the **Wall Anchors (H)** provided into the wall with hammer.




**STEP 9:** Install the **Metal Brackets (C)** to the wood studs by screw driver.

**Screw (F):**  
M5 x 50mm long  
6pcs




**STEP 10:** Hang the **Vanity (A)** to the wall and then connect the **Vanity (A)** to the **Wood Cleat (B)** with the 2 **Screws (F)** provided.



## INSTALLATION INSTRUCTIONS

**SKU: VA3621V8WH**


STEP 11: Connect the **Metal Brackets (C)** to the **Vanity (A)** with **Screws (G)**.




**Confidentialal : A**

**PROHIBIT COPY**

STEP 12: Connect the electrical wire to the wall switch for turning on/off.



STEP 13: Apply the silicone to the top of the **Vanity (A)** and then install the **Top (D)** onto the **Vanity (A)** with the help from another person.



STEP 14: Let the vanity sit for 24 hours before use.

