


## INSTALLATION INSTRUCTIONS

**Confidentialal : A**

**SKU: VA4820V14GN**

**PROHIBIT COPY**

- Prior to installation please check received items against the Packing List .If any part is missing or damaged, please do not return the product to the store and contact us;  
Call: (302)336-8180  
Email: vanityinservice@gmail.com
- Protect all surfaces from sharp objects , high heat sources,direct prolonged sunlight and chemical hazards .
- Professional installation is recommended !



## INSTALLATION INSTRUCTIONS


**Confidentialal : A**

**SKU: VA4820V14GN**

**PROHIBIT COPY**

### NOTE

1. Ceramic sink: cUPC certified.



2. LED light :

a. The LED light is replaceable, if it is damaged, please contact us ;

Call: (302)336-8180


Email: [vanityinservice@gmail.com](mailto:vanityinservice@gmail.com)

b. LED light should be connected to the wall switch for turning on/off.


c. UL certified & IP67 for water proof.




Marble top with ceramic sink




Up Vanity




Down Vanity



LED light  
( pre-assembled on the  
bottom of the vanity )



wall switch



**INSTALLATION INSTRUCTIONS**


**Confidentialal : A**

**SKU: VA4820V14GN**


**PROHIBIT COPY**

**PACKING LIST**


A1 Up Vanity  
1 PC




A2 Down Vanity  
1 PC




B Wood Cleat  
2 PCS




C Metal Bracket  
4 PCS



D TOP  
1 PC



E Wood Screw  
8 PCS



M6 x 70

F Wood Screw  
14 PCS



M5 x 50

G Wood Screw  
8 PCS



M4 x 15


H Wall Anchor  
22 PCS



I Metal Washers  
8 PCS



J Backsplash  
1 PC



**TOOLS REQUIRED**

Drill Bits



Ø3/8" (8mm)dia.

HSS

Screw Driver




Drill



Level



Knife



Glove




MASONRY DRILL BIT FOR  
TILE Ø3/8" (8mm)



Safety Glasses



Silicone



Measuring Tape



Soft Head  
Hammer




Pencil



Wood stud finder



Shovel



**INSTALLATION INSTRUCTIONS**

**SKU: VA4820V14GN**


**Confidentialal : A**

**PROHIBIT COPY**


- STEP 1: ☐ Use a wood stud finder to locate the wood studs behind the walls.
- ☐ Use a pencil to mark the installation location for the **Wood Cleats (B)**.
- ☐ Use a level to ensure the **Wood Cleats (B)** will be level before installing to the wall.

**NOTE** Make sure the screw holes must be on the wood studs otherwise the vanity will fall out because the dry wall cannot hold the cabinet.

vanity	hole	a	b	c
36"	3	12"	12"	-
48"	4	12"	12"	12"
60"	4	12"	24"	12"




- STEP 2: Drill the anchor holes according to the marks using a drill.



## INSTALLATION INSTRUCTIONS

**SKU: VA4820V14GN**


**STEP 3:** Install the **Wall Anchors (H)** provided into the wall with hammer.




**Confidential : A**

**PROHIBIT COPY**


**STEP 4:** Install the **Wood cleats (B)** to the wood studs by screw driver.



**STEP 5:** With help from another person, carefully hang the **Up Vanity (A1)** and **Down Vanity (A2)** onto the **Wood Cleats (B)**.



**STEP 6:** Using a pencil to mark the installation location for the **Metal Brackets (C)**.




## INSTALLATION INSTRUCTIONS

**SKU: VA4820V14GN**

**STEP 7:** Carefully remove the **Up Vanity (A1)** and **Down Vanity (A2)** with the help from another person, and then drill the anchor holes according to the marks using a drill.


Anchor Hole  
dia= Ø3/8"(8mm)  
Depth=3.2"



**Confidentialal : A**


**PROHIBIT COPY**

**STEP 8:** Install the **Wall Anchors (H)** provided into the wall with hammer.




**STEP 9:** Install the **Metal Brackets (C)** to the wood studs by screw driver.

**Screw (F):**  
M5 x 50mm long  
6pcs




**STEP 10:** Hang the **Up Vanity (A1)** and **Down Vanity (A2)** to the wall and then connect the **Up Vanity (A1)** to the **Wood Cleat (B)** with the 2 **Screws (F)** provided.



## INSTALLATION INSTRUCTIONS

**SKU: VA4820V14GN**


**STEP 11:** Connect the **Metal Brackets (C)** to the **Up Vanity (A1)** and **Down Vanity (A2)** with **Screws (G)**.




**Confidentialal : A**

**PROHIBIT COPY**

**STEP 12:** Connect the electrical wire to the wall switch for turning on/off.



**STEP 13:** Apply the silicone to the top of the **Up Vanity (A1)** and then install the **Top (D)** onto the **Up Vanity (A1)** with the help from another person.



**STEP 14:** Installing the **Backsplash (J)**

- Apply silicone to the back of the **Backsplash (J)**.
- Place the **Backsplash (J)** on the **Up Vanity (A1)**. Be sure to align the **Backsplash (J)** with the top of the **Up Vanity (A1)**.
- Allow the silicone to dry before using the vanity.
- Gently remove excess glue from the connecting area by shovel.
- Let the Vanity and Backsplash sit for 24 hour before use.

