

C4: Operating time of the "Samsung Galaxy Buds Pro" earbuds in a regular mode

Type	Priority	Estimate	References
Performance	High	None	None
Automation Type			
None			

Preconditions

**Environment:** Android 5 or higher

- 1) Earbuds: Samsung Galaxy Buds Pro (100 % charged)
- 2) Smartphone (100 % charged)
- 3) Installed offline music player on the smartphone
- 4) Downloaded audio file on the smartphone
- 5) Earbuds are connected to the smartphone via Bluetooth
- 6) The smartphone is in "Airplane Mode"
- 7) The smartphone is not connected to a Wi-Fi network

Steps

1	Open the installed music player	The "Songs" page is open
2	Play the downloaded audio file	Earbuds play the sound of the audio file for 8 hours