







The devkit being used is a different one. and has less pins than the one showed here!!!
(I should create a symbol for the new one, but right now works)

SPI0: GPIO6–11 are usually connected to the SPI flash integrated on the module and therefore should not be used for other purposes.

JTAG: GPIO12–15 are usually used for inline debug.



Associació Cultural TGK

Sheet: /

File: compta–birres.kicad_sch

Title: Root


Size: A4

Date: 2024–08–08

Rev: 1.3

KiCad E.D.A. 8.0.4

Id: 1/10



Associació Cultural TGK

Sheet: /Power/
File: power.kicad_sch


Title: Power

Size: A4 Date: 2024-08-08

KiCad E.D.A. 8.0.4

Rev: 1.0

Id: 2/10



Associació Cultural TGK

Sheet: /Buttons/
File: buttons.kicad_sch

Title: Buttons

Size: A4 Date: 2024-08-04
KiCad E.D.A. 8.0.4

Rev: 1.1
Id: 3/10

Id: 4/10

