







External CAN connections




Power supply connections



Magic CAN Node connections



SV1 allows SIGNAL_IN to be connected to any of the MCN inputs.



External signal input

