


Joystick to ROV movement Diagram

Normal Joystick Movement
(push button not depressed)



Joystick movement during interrupt
(push button depressed)

