



△ C1 is the bypass cap for the VPU, at least 1uF



△ RSH is for pulling SEL High  
RSL is for pulling SEL Low

△ RC & RD are for adjusting resistance of the CLK and DATA lines.



△ JPH is for PH JST Connector, JSH is for SH JST Connector. Only populate one.

Title			
Size	Number		Revision
Letter			
Date:	8/22/2023		Sheet of
File:	C:\Users\...\VPU_Breakout_v2.SchDoc		Drawn By: