


BLOCK DIAGRAM

ELECTR•NO



Index	
A	Power supply block & sub block
	DAQ & its TB /Block & sub block
	Sensors & Its SC Block & sub block
B	Actuators & its Drivers Block & sub block
	Panel Box, containers & sub block
	3 Phase AC
C	1 Phase AC
	Earthing
	DC 220 V
D	DC 24 V
	DC 15 V
	DC 12 V
E	DC 9 V
	DC 5 V
	DC 3.3 V
F	DC Ground
	PC DAQ interface
	DAQ AO's
G	DAQ AI
	DAQ DIO
	Control Transfer
H	Liquid Flow
	Air Flow
	Voltage Sensor
	Current Transformer
	Current Sensor
	Limit Switch
	DC FAN