

◆GROUNDING INSTRUCTIONS

3. Connect the grounding plug to a properly grounded outlet; an approved ground fault circuit interrupter (GFI) outlet is recommended.
4. For your safety, the bidet has a built-in GFI. To reset it, remove the power cord plug from the wall outlet; then plug it back in.
5. If the grounding instructions cause any confusion or doubt during installation, check with a qualified electrician to assure the product is properly grounded.
6. The bidet is factory equipped with a specific electric cord and plug to permit connection to a proper electric circuit. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product. Do not modify the plug provided if it will not fit the outlet, have the proper outlet installed by a qualified electrician. If the product must be reconnected for use on a different type of electric circuit, the reconnection should be made by qualified service personnel. The green colored rigid ear, lug, and the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by the screw.

7. The bidet must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.
8. The bidet has a grounding wire with a grounding plug. Do not tamper with the plug in any way. If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer coating that is green, with or without yellow stripes, is the grounding wire.
9. The plug must be plugged into an outlet that is properly installed and grounded. Improper use of the grounding plug can result in a risk of electric shock.
10. If it is necessary to use an extension cord, use only a three wire extension cord that has a three-blade grounding plug, and a three-slot receptacle that will accept the plug on the product. Replace or repair a damaged cord.

SAVE THESE INSTRUCTIONS.