

# Stability Analysis

- 1 Bounded-Input Bounded-Output (BIBO) Stability
- 2 Asymptotic Stability
- 3 Lyapunov Stability
- 4 Linear Approximation of a Nonlinear System

## Bounded-Input Bounded-Output (BIBO) stability

Definition: For any constant  $N, M > 0$   
Any bounded input yields bounded output, i.e.

$$|u(t)| \leq N < \infty \rightarrow |y(t)| \leq M < \infty$$

---

For linear systems:

$$T(s) = \frac{p(s)}{q(s)} = C(sI - A)^{-1} B$$

BIBO Stability  $\Leftrightarrow$  All the poles of the transfer function lie in the LHP.

$$q(s) = 0$$

Characteristic  
Equation

Solve for poles of the transfer function  
 $T(s)$

## Asymptotic stability

When  $u(t) = 0$ , i. e. the system  $\dot{x} = Ax$   
 $x(t) \rightarrow 0$  as  $t \rightarrow \infty$

For linear systems:

$$\begin{aligned}\dot{x} &= Ax + Bu \\ y &= Cx\end{aligned}$$

Asymptotically stable  $\Leftrightarrow$  All the eigenvalues of the  $A$  matrix  
have negative real parts  
(i.e. in the LHP)

$$T(s) = \frac{p(s)}{q(s)} = C(sI - A)^{-1}B = \frac{C \operatorname{adj}[sI - A]B}{|sI - A|}$$

$|sI - A| = 0$   Solve for the eigenvalues for A matrix

**Note:** Asy. Stability is independent of  $B$  and  $C$  Matrix

## Asy. Stability from Model Decomposition

Suppose that all the eigenvalues of  $A$  are distinct.  $A \in R^{n \times n}$

Let  $v_i$  the eigenvector of matrix  $A$  with respect to eigenvalue  $\lambda_i$

i.e.  $\lambda_i$ , satisfying  $Av_i = \lambda_i v_i$ ,  $i = 1, \dots, n$

Coordinate Matrix  $T = [v_1, v_2, \dots, v_n]$

$$\Rightarrow \dot{\xi} = T^{-1}AT\xi$$

$$\Rightarrow \begin{bmatrix} \dot{\xi}_1 \\ \dot{\xi}_2 \\ \vdots \\ \dot{\xi}_n \end{bmatrix} = \begin{bmatrix} \lambda_1 & 0 & 0 \dots & 0 \\ 0 & \lambda_2 & 0 & 0 \\ \vdots & 0 & \ddots & \vdots \\ 0 & 0 & \dots & \lambda_n \end{bmatrix} \begin{bmatrix} \xi_1 \\ \xi_2 \\ \vdots \\ \xi_n \end{bmatrix}$$

$$\bar{A} = T^{-1}AT$$

$$\bar{B} = T^{-1}B$$

$$\bar{C} = CT$$

$$\dot{z} = T^{-1}ATz + T^{-1}Bu$$

$$y = CTz + Du$$

$$x(t) = T\xi(t) = v_1 e^{\lambda_1 t} \xi_1(0) + v_2 e^{\lambda_2 t} \xi_2(0) + \dots + v_n e^{\lambda_n t} \xi_n(0), \quad \xi(0) = T^{-1}x(0)$$

Hence, system Asy. Stable  $\Leftrightarrow$  all the eigenvalues of  $A$  lie in the LHP

## Asymptotic Stability versus BIBO Stability

*In the absence of pole-zero cancellations, transfer function poles are identical to the system eigenvalues. Hence BIBO stability is equivalent to asymptotical stability.*

Conclusion: If the system is both controllable and observable, then  
BIBO Stability  $\Leftrightarrow$  Asymptotical Stability

### Methods for Testing Stability

- Asymptotically stable
  - All the eigenvalues of  $A$  lie in the LHP
- BIBO stable
  - Routh-Hurwitz criterion
  - Root locus method
  - Nyquist criterion
  - ....etc.

## Lyapunov Stability

A state  $x_e$  of an autonomous system is called an equilibrium state, if starting at that state the system will not move from it in the absence of the forcing input.

In other words, consider the system  $\Rightarrow \dot{x} = f(x(t), u(t))$


equilibrium state  $x_e$  must satisfy  $\Rightarrow f(x_e, 0) = 0, \quad \forall t \geq t_0$

Example:

$$\dot{x} = \begin{bmatrix} 0 & 1 \\ -2 & -3 \end{bmatrix} x + \begin{bmatrix} 1 \\ 1 \end{bmatrix} u(t)$$


Set  $u(t) = 0,$

$$\text{we get } \begin{bmatrix} 0 & 1 \\ -2 & -3 \end{bmatrix} \begin{bmatrix} x_{1e} \\ x_{2e} \end{bmatrix} = 0 \Rightarrow \begin{bmatrix} x_{1e} \\ x_{2e} \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \end{bmatrix}$$



**Definition:** An equilibrium state  $x_e$  of an autonomous system is stable in the sense of Lyapunov if for every  $\varepsilon > 0$ , exist a  $\delta(\varepsilon) > 0$  such that


$$\|x_0 - x_e\| < \delta \Rightarrow \|x(t, x_0) - x_e\| < \varepsilon \quad \forall t \geq t_0$$



Definition: An equilibrium state  $x_e$  of an autonomous system is *asymptotically stable* if

- (i) it is stable
- (ii) there exist a  $\delta_e > 0$  such that

$$\|x_0 - x_e\| < \delta_e \Rightarrow \|x(t) - x_e\| \rightarrow 0, \text{ as } t \rightarrow \infty$$





## Lyapunov Theorem

Consider the system  $\dot{x} = f(x)$  (1)

Eq. State:  $x_e = 0$   $\Rightarrow$   $(\because f(0) = 0)$

A function  $V(x)$  is called a Lyapunov function  $V(x)$  if

$$(1) \quad V(x) > 0, \forall x \neq 0$$

$$(2) \quad V(0) = 0 \quad \text{for} \quad x = 0$$

$$(3) \quad \frac{dV(x)}{dt} = \frac{dV(x)}{dx} f(x) \leq 0$$

Then eq. state of the system (1) is **stable**.


Moreover, if the Lyapunov function satisfies

$$\frac{dV(x)}{dt} < 0, \forall x \neq 0 \quad \text{and} \quad \frac{dV(x)}{dt} = 0 \Leftrightarrow x = 0$$

**Then eq. state of the system (6.1) is asy. stable.**

## Explanation of the Lyapunov Stability Theorem

1. The derivative of the Lyapunov function along the trajectory is **negative**.
2. The Lyapunov function may be consider as an **energy function** of the system.



**Lyapunov's method for Linear system:**  $\rightarrow \dot{x} = Ax$  where  $|A| \neq 0$

The eq. state  $x = 0$  is asymptotically stable.

$\Leftrightarrow$

For any p.d. matrix  $Q$ , there exists a p.d. solution of the Lyapunov equation

$$A^T P + PA = -Q$$

Proof: Choose

$$V(x) = x^T P x$$

$$\begin{aligned}\dot{V}(x) &= \dot{x}^T P x + x^T P \dot{x} \\ &= x^T A^T P x + x^T P A x \\ &= x^T (A^T P + P A) x \\ &= -x^T Q x < 0, \text{ for } x \neq 0\end{aligned}$$

$$\because A^T P + P A = -Q$$

**Hence, the eq. state  $x=0$  is asy. stable by Lapunov theorem.**

## *Asymptotically stable in the large*

( globally asymptotically stable)

- (1) The system is asymptotically stable for all the initial states  $x(t_0)$  .
- (2) The system has only one equilibrium state.
- (3) For an LTI system, asymptotically stable and globally asymptotically stable are equivalent.

### **Lyapunov Theorem (Asy. Stability in the large)**

If the Lyapunov function  $V(x)$  further satisfies

$$(i) \quad \forall \|x\| < \infty, V(x) < \infty$$

$$(ii) \quad \|x\| \rightarrow \infty, V(x) \rightarrow \infty$$

Then, the (asy.) stability is global.

**Example:**

$$\dot{x} = \begin{bmatrix} 0 & 1 \\ -1 & -1 \end{bmatrix} x$$

Let  $Q = I$ , Assume  $P = \begin{bmatrix} p_{11} & p_{12} \\ p_{12} & p_{22} \end{bmatrix}$

Solve for  $A^T P + P A = -I$

$$\begin{bmatrix} 0 & -1 \\ 1 & -1 \end{bmatrix} \begin{bmatrix} p_{11} & p_{12} \\ p_{12} & p_{22} \end{bmatrix} + \begin{bmatrix} p_{11} & p_{12} \\ p_{12} & p_{22} \end{bmatrix} \begin{bmatrix} 0 & 1 \\ -1 & -1 \end{bmatrix} = \begin{bmatrix} -1 & 0 \\ 0 & -1 \end{bmatrix}$$

$$\Rightarrow P = \begin{bmatrix} p_{11} & p_{12} \\ p_{12} & p_{22} \end{bmatrix} = \frac{1}{2} \begin{bmatrix} 3 & 1 \\ 1 & 2 \end{bmatrix}$$

$$|p_{11}| = 3 > 0 \quad |P| = 5 > 0 \quad \longrightarrow \quad P \text{ is p.d.}$$

System is asymptotically stable

The Lyapunov function is:

$$V(x) = x^T P x = \frac{1}{2} (3x_1^2 + 2x_1x_2 + 2x_2^2)$$
$$\dot{V}(x) = -(x_1^2 + x_2^2)$$

## Linear approximation of a function around an operating point $x_e$

Let  $f(x)$  be a differentiable function.

Expanding the nonlinear equation into a *Taylor series* about the operation point  $x_e$ , we have

$$f(x) = f(x_e) + \left. \frac{df(x)}{dx} \right|_{x=x_e} \frac{(x - x_e)}{1!} + \left. \frac{d^2 f(x)}{dx^2} \right|_{x=x_e} \frac{(x - x_e)^2}{2!} + \dots$$


Neglecting all the high order terms, to yield

$$f(x) \approx f(x_e) + \left. \frac{df(x)}{dx} \right|_{x=x_e} \frac{(x - x_e)}{1!} = f(x_e) + m \cdot (x - x_e)$$

$$f(x) - f(x_e) \approx m \cdot (x - x_e)$$

where

$$m = \left. \frac{df(x)}{dx} \right|_{x=x_e}$$



## Multi-dimensional Case:

Let  $x$  be a  $n$ -dimensional vector, i.e.  $x \in R^n$

$$\begin{aligned} & f(x_1, \dots, x_n) \\ &= f(x_{1e}, \dots, x_{ne}) + \frac{\partial f}{\partial x_1} \Big|_{x=x_e} (x_1 - x_{1e}) + \frac{\partial f}{\partial x_2} \Big|_{x=x_e} (x_2 - x_{2e}) + \dots + \frac{\partial f}{\partial x_n} \Big|_{x=x_e} (x_n - x_{ne}) \\ &= f(x_{1e}, \dots, x_{ne}) + \frac{\partial f}{\partial x} \Big|_{x=x_e} (x - x_e), \quad \text{where } \frac{\partial f}{\partial x} \Big|_{x=x_e} = \left[ \frac{\partial f}{\partial x_1} \Big|_{x=x_e}, \dots, \frac{\partial f}{\partial x_n} \Big|_{x=x_e} \right] \end{aligned}$$

Let  $f$  be a  $m$ -dimensional vector function, i.e.  $f(x): R^n \rightarrow R^m$

$$f(x_1, \dots, x_n) = \begin{bmatrix} f_1(x_1, \dots, x_n) \\ f_2(x_1, \dots, x_n) \\ \vdots \\ f_m(x_1, \dots, x_n) \end{bmatrix}$$

## Linear approximation of a function around an operating point $x_e$

Special Case:  $n=m=2$

$$f(x) - f(x_e) \approx \left. \frac{\partial f}{\partial x} \right|_{x=x_e} (x - x_e) = A(x - x_e)$$

where  $x = [x_1, x_2]^T$  and

$$\left. \frac{\partial f}{\partial x} \right|_{x=x_e} = \begin{bmatrix} \left. \frac{\partial f_1}{\partial x_1} \right|_{x=x_e} & \left. \frac{\partial f_1}{\partial x_2} \right|_{x=x_e} \\ \left. \frac{\partial f_2}{\partial x_1} \right|_{x=x_e} & \left. \frac{\partial f_2}{\partial x_2} \right|_{x=x_e} \end{bmatrix} = A$$



## Linear approximation of an autonomous nonlinear systems $\dot{x}(t) = f(x(t))$

Let  $x_e$  be an equilibrium state, from

$$\dot{x} = f(x(t)) \approx A(x - x_e)$$

where

$$A = \left. \frac{\partial f}{\partial x} \right|_{x=x_e} = \begin{bmatrix} \left. \frac{\partial f_1}{\partial x_1} \right|_{x=x_e} & \left. \frac{\partial f_1}{\partial x_2} \right|_{x=x_e} \\ \left. \frac{\partial f_2}{\partial x_1} \right|_{x=x_e} & \left. \frac{\partial f_2}{\partial x_2} \right|_{x=x_e} \end{bmatrix}$$

The linearization of  $\dot{x}(t) = f(x(t))$  around the equilibrium state  $x_e$  is

$$\dot{z} = Az \quad \text{where} \quad z = x - x_e \quad \text{and} \quad \dot{z} = \dot{x} - \dot{x}_e = \dot{x}$$

## Example : Pendulum oscillator model

From Newton's Law we have


$$J \frac{d^2 \theta}{dt^2} + MgL \sin \theta = 0$$

where  $J$  is the inertia.


Define  $x_1 = \theta, x_2 = \dot{\theta}$

$$\Rightarrow \begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} x_2 \\ -\frac{MgL}{J} \sin x_1 \end{bmatrix}$$

We can show that  $x_e = 0$  is an equilibrium state.



(a)



(b)

Example (cont.):

Method 1:  $f_1(x_2) = x_2 \Rightarrow f_1(x_2) - f_1(0) = (x_2 - 0) = z_2$

$$f_2(x_1) = \sin x_1$$

$$\Rightarrow f_2(x_1) - f_2(0) = \sin x_1 - \sin 0 \approx \left. \frac{d(\sin x_1)}{dx_1} \right|_{x_1=0} (x_1 - 0) = z_1$$

The linearization around the equilibrium state  $x_e = 0$  is

$$\begin{bmatrix} \dot{z}_1 \\ \dot{z}_2 \end{bmatrix} = \begin{bmatrix} z_2 \\ -\frac{MgL}{J} z_1 \end{bmatrix}$$

where  $z = x$  and  $\dot{z} = \dot{x}$

### Example (cont.):

Method 2:  $f_1(x) = x_2, \quad f_2(x) = -\frac{MgL}{J} \sin x_1$

$$\begin{aligned} \left. \frac{\partial f}{\partial x} \right|_{x=x_e} &= \begin{bmatrix} \left. \frac{\partial f_1}{\partial x_1} \right|_{x=x_e} & \left. \frac{\partial f_1}{\partial x_2} \right|_{x=x_e} \\ \left. \frac{\partial f_2}{\partial x_1} \right|_{x=x_e} & \left. \frac{\partial f_2}{\partial x_2} \right|_{x=x_e} \end{bmatrix} \\ &= \begin{bmatrix} 0 & 1 \\ -\frac{MgL}{J} & 0 \end{bmatrix} = A \end{aligned}$$

The linearization around the equilibrium state  $x_e = 0$  is

$$\begin{bmatrix} \dot{z}_1 \\ \dot{z}_2 \end{bmatrix} = Az = \begin{bmatrix} 0 & 1 \\ -\frac{MgL}{J} & 0 \end{bmatrix} \begin{bmatrix} z_1 \\ z_2 \end{bmatrix} = \begin{bmatrix} z_2 \\ -\frac{MgL}{J} z_1 \end{bmatrix}$$

where  $z = x$  and  $\dot{z} = \dot{x}$