

Weak-plane plasticity. 10 'sideways' excavations with compressive softening. Subsidence

