











# Soldering Workshop

DroidCON Style




# Overview

-  Safety, Safety, Safety
-  Basic Tools, Materials
-  Work Area & Tool Setup
-  Procedures
  -  Cleaning, Wetting and Pre-Heating
  -  Solder Flow
  -  Iron Contact
  -  Solder Fillet
-  Workshop Project - A DroidCON Exclusive
-  Have Fun!



# Safety, Safety, Safety

 Two words: MOLTEN METAL

 It's seriously HOT!!! (Up to 850°F or 455°C)

 Don't pick up like a Pencil... you will only do this once

 Only touch the plastic handle of the iron

 Keep hair and skin away from the soldering iron

 Lead Solder

 Melting not the issue

 Handling lead is the issue

 Use Lead Free if possible - RoHS

 Solder Fumes

 Ventilation and/or fume extractor

 Flux or Rosin vapor - Not LEAD

 Smell, you'll get to love it.



# Basic Tools and Materials

 Soldering Pen 20W to 40W


 Small conical or chisel tip

 Holder

 Sponge or Brass Sponge

 Solder

 64/37 (Tin/Lead\*) Best

 60/40 Good, but careful about movement while solder is still fluid, it can result in cold joint.

 No Clean Flux or Water Soluble

 Lead Free RoHS

 .31 to .20 diameter

 Flush Cutters better than Diagonal Cutters



# Setup Your Work Area & Tools



# Flush Cutters



# Solder



# Solder Wick

# Soldering Iron Stand



# Sponge Well Wet











# Soldering Iron in stand?

# Soldering Iron Plugged In?

# Soldering Iron Hot?




# Basic Procedure

-  Make sure the soldering area is clean
  -  No grease, no oxide, no oils
-  Put the items together
-  Wet the area with flux if needed
  -  Flux- Latin *fluxus* for FLOW, cleans, protects copper against oxidation while. If you burn off the Flux = poor solder
-  Pre-heat the area with soldering iron
-  Apply and feed solder at the joint
-  Remove solder when sufficient solder has been applied
-  Then remove the iron.
-  Get in, get it on, get out...





Yes we are still talking about Soldering!




# Basic Procedure - cont.




# Iron Contact Area

-  Pre-Heating is critical and only takes a half second or so.
-  Iron tip needs good contact with BOTH parts
-  Trace and Component Leads
-  Heat transfer with small solder bridge works well







Not enough




Good




# Solder Fillet Flow


-  Minimum solder will not withstand stress
-  Excessive solder can lead to stressed and cold joints
-  Optimal solder joints looks neat, clean and professional
-  Smoke & fumes are from the Flux/Rosin not lead.



Minimum



Optimal













Excessive

 Remember: Flux- Latin *fluxus* for FLOW, cleans, protects copper against oxidation while. If you burn off the Flux = poor solder



# Tips and Techniques







-  Use Breadboard to place and hold headers for you
-  Use Solder bridge to get heat into the lead and pad
-  Get it hot enough.
-  Use appropriate temperature
-  Use appropriate soldering pen tip for the job.
-  Keep the tip clean
-  Don't have sponge and brass sponge? Wet paper towel
-  Practice on old boards or bad PCBs... got plenty of them.
-  Workmanship
-  Never use a SOLDER CANNON on PCBs.



# Solder Cannons



# Workshop Project


-  DroidCON Exclusive
-  Simple Through-Hole (PTH) Kit
-  Lots of typical solder joints
-  Takes about 30 to 60 minutes to build
-  Ask questions about soldering!
-  Have Fun!



So what are we going to build?



# DroidCONuino




- 👤 Arduino Uno Compatible MicroController w UNO bootloader
- 👤 Atmel 328P 28DIP or SMD
- 👤 6 Servos
- 👤 Teeces 7219/7221 Logics Control
- 👤 1 x i2c Bus
- 👤 1 amp 5v regulator
- 👤 External Power Input (<15 volt)
- 👤 Bread Board Compatible
- 👤 FTDI & ICSP Connections
- 👤 Based on AdaFruit's Boarduino DC design!



# Part Inventory & Identification


PCB



IC1



SOC



X1



JACK




IC2




C1, C2  
C5, C6



C3



C4



R1



R2, R3



SWITCH

D1



D2



D3













JUMPER





# DroidCONuino - Power Supply




-  Install Capacitors C1 & C5 (.1uf 50V - Little & beige)
-  Install Capacitor C4 (100uf 6.3v - rather short) LONG LEG goes into +
-  Install Capacitor C3 (47uf 25v - Tallest) LONG LEG goes into +
-  Install Diode D1 (1N4001)... notice the polarity Band matches Band
-  Install 7805C 5V Regulator IC2. Match orientation with diagram
-  Install Resistor R2 (1k Ohm Brown-Black-RED-Gold)
-  Install LED D2 (3mm Green) LONG LEG goes into +
-  Install Power JACK - Will fit one way into top of PCB
-  Install 1x3 Header & then place JUMPER on pin marked EXT & center
-  Smoke Test it!!!






# Should Look Like This




# DroidCONuino - MCU Section




- 👤 Install Resistor R3 (1k Ohm Brown-Black-RED-Gold)
- 👤 Install LED D3 (3mm RED). LONG LEG goes into +
- 👤 Install X1 (16 MHz Ceramic Resonator) Notice it has 3 leads and no polarity
- 👤 Install Resistor R1 (10k Ohm Brown-Black-ORANGE-Gold)
- 👤 Install Capacitor C2 & C6 (.1uf 50V - Little & beige)
- 👤 Install SWITCH for Reset into top of PCB. Careful of the pins
- 👤 Install IC1 SOCKET into top of PCB.



# Should Look Like This




# DroidCONuino - Headers



- 👤 (OPTIONAL) Install 2x3 header into ISCP, beside the reset SWITCH
- 👤 Install 1x6 header into the USB/FTDI section into the TOP of PCB
- 👤 Install 3x6 header into SERVO section into the TOP of the PCB
- 👤 Install 1x4 header into the I2C section, TOP of the PCB
- 👤 Install 1x5 header into the LOGICS section, TOP of the PCB
- 👤 (OPTIONAL) If your going to use with a BREADBOARD, install headers onto the BREADBOARD, LONG legs into BREADBOARD.




# Should Look Like This





# DroidCONuino - Atmel 328P




- 👤 STATIC Sensitive... meaning static can kill it.
- 👤 Dump static to a ground if possible... touch the metal faucet in the sink
- 👤 Align 328P with IC1 Socket indentation.
- 👤 Gently set 328P onto socket
- 👤 Verify the pins are aligned with socket receptacles
- 👤 Press 328P into the socket

Indentation →







Pin 1 →



# Completed?



# Smoke Test

-  Apply 6V to 9V DC via Power JACK
-  Red LED D3 should blink on & off.
-  It will also rotate any SERVOS attached to Servo 1-6
-  Test Maxim 72xx Bus
-  If it does not blink or if you let the Magic Blue Smoke out  
At DroidCON III we'll learn to troubleshoot!
-  Ask one of the instructors to load a cool DroidCONuino  
demo sketch on it for you.





Q

&

A

