


Ambient Light Sensor


How to use:

Plug in power (carefully!). Shine a light on the photoresistor. Press either the A or B button on the BBC Micro:bit and the reading from the sensor is scrolled across the 5x5 LED screen.


1: Plug in JST connector to BBC Micro:bit



2: Press either the A or B button on the BBC Micro:bit





3: The light intensity reading will scroll across the LED



Build:

Image of code at:
<https://github.com/lordjim2001/MFSN2020-01>



fritzing

Code:

Code image located at: <https://github.com/lordjim2001/MFSN2020-01>

