


CF 10
Flange-flange distance to high tolerance
(~.1 mm)

CF 4-5/8
Must be vertically centered to high tolerance
(~.1 mm)



Angular tolerance:
Must have a clear view into opposing window

SECTION A-A

CF 2-1/8

CF 2-3/4