

Colour codes

WS White **RT** Red
BL Blue **GN** Green
GR Grey **VI** Violet
GE Yellow **SW** Black
BR Brown **OR** Orange


Key to items

- 1 Battery
- 7 Luggage compartment fusebox
- 9 Car access system
- 18 Passenger compartment fusebox
- 97 Instrument cluster control unit
- 98 Outside air temp. sensor
- 99 LH fuel tank sensor
- 100 RH fuel tank sensor/fuel pump
- 101 Washer fluid level switch
- 102 Handbrake switch
- 103 Coolant level switch
- 104 Heating and air conditioning control unit


Diagram 10

H47045

Typical instruments & indicator lights



Typical heater blower



Typical heated rear window

