



**Haynes**  
*shows you how*

---

**BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual**

## Every 50,000 miles

Replace the oxygen sensor(s) ( [Section 34](#) )

---

© 2024 Haynes Manuals, Inc. Contact us