



Haynes
shows you how

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

26 Tie-rod - replacement

- 1 Remove the steering_gear boot as described in [Section 24](#) .
- 2 Unscrew the tie-rod from the end of the steering_gear.
- 3 Install the new locking plate to the steering_gear, making sure it is locating tabs are correctly seated in the steering gear grooves.
- 4 Screw in the tie-rod and tighten it to the specified torque.
- 5 Reinstall the steering boot as described in [Section 24](#) .

© 2024 Haynes Manuals, Inc. Contact us