

**Haynes**
shows you how

[BMW 3-Series \(92-98\) & Z3 \(96-98\) Haynes Online Manual](#)

12 Ignition switch - removal and installation

The ignition switch is integral with the steering column lock, and can be removed (see [Chapter 10](#)).

© 2024 Haynes Manuals, Inc. Contact us