





27128 Address	System Address	Contents (If color module is not installed)	27128 Address	System Address	Contents (If color module is installed)
0000-FFFF	C000-CFFF	Loader-2	0000-FFFF	C000-CFFF	Loader-2
0000-FFFF	C000-CFFF	Monitor-2	0000-FFFF	C000-CFFF	Monitor-2
0000-FFFF	C000-CFFF	BASIC	0000-FFFF	C000-CFFF	BASIC
0000-FFFF	C000-CFFF	BASIC	0000-FFFF	C000-CFFF	BASIC
0000-FFFF	C000-CFFF	BASIC	0000-FFFF	C000-CFFF	BASIC
0000-FFFF	C000-CFFF	Unused	0000-FFFF	C000-CFFF	Unused
0000-FFFF	C000-CFFF	Used by 8255, computer cannot read ROM from here	0000-FFFF	C000-CFFF	Used by 8255, computer cannot read ROM from here



Русский текст в этой схеме был переведен автоматически. Если вы хотите прислать исправления к русскому переводу, пожалуйста, напишите мне на yort37@yandex.ru или отправьте сообщение GlueLogic на zx-pk.ru.