

The background of the entire page is a pixelated representation of the Frogger game environment. It features a blue sky with white clouds at the top, a green grassy area with small yellow flowers below it, a grey brick wall, and a grey road with white dashed lines. At the bottom, there is a brown ground area with grey rocks and a small green frog.

INSTRUCTION BOOKLET

FROGGER

GAME TEAM 7



TABLE OF CONTENTS

STORY

YOUR GO-BOARD

CONTROLLER OPERATION

PLAYING THE GAME

GET HELP

SAFETY AND HANDLING



STORY


Meet Froggy, a brave little frog with a big heart and a simple mission: to reunite with his family in their cozy home by the lake. The lake is where Froggy's family waits, surrounded by lush greenery and gentle waters, a place where they spend their days together. But for Froggy, the journey back is far from easy.

One stormy night, strong winds swept Froggy far from his home, carrying him across rivers, forests, and busy roads filled with speeding cars and bustling traffic. Now, Froggy finds himself on the other side of a dangerous highway, with only one goal in mind: to cross all the obstacles and make it back to the safety of the lake.

Your goal is to help Froggy navigate through these perilous roads and reach the lake, where his family eagerly awaits. But be careful! The journey is filled with challenges!

Froggy's family is counting on you! With your help, Froggy can overcome the challenges and hop his way back home, where his loved ones await with open arms (and webbed feet). But remember, time is of the essence, and you'll need quick reflexes and sharp thinking to guide Froggy safely through each level. Will you be the

one to guide Froggy back to the warmth and safety of his family by the lake? The adventure starts now—help Froggy find his way home!






YOUR GO-BOARD

This section is dedicated to helping you set up your Go-Board. Make sure that your Go-Board matches the model shown below, as this guide is specifically designed for this board. If your board differs from the one described, please obtain the correct model before proceeding.

VGA

USB



**Two
7-Segment
Displays**

4 Switches



SET UP AND GET STARTED

