

Example Response	{ "response_code":0 }
------------------	-----------------------------

5.23. recallScene

Scene selection from the scene number.

It is valid only when "scene" exists in zone – func_list of /system/getFeatures.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone Values: "main" / "zone2" / "zone3" / "zone4"
num	integer	yes	Specifies scene number Values: Scene number gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/recallScene?num=<num>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/recallScene?num=1

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to "Response Code List" for details

Example Response	{ "response_code":0, }
------------------	------------------------------

5.24. setContentsDisplay

Set the screen display of each Zone's screen.

It is valid only when "contents_display" exists in zone – func_list of /system/getFeatures.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target Zone Values: "main" / "zone2" / "zone3" / "zone4"
enable	boolean	yes	Specifies display status of screen Values: true (enable) , false (disable)

URI	<BaseURL>/v1/<zone>/setContentsDisplay?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setContentsDisplay?enable=false