

		specific API to retrieve appropriate playback info Values: "none" / "tuner" / "netusb" / "cd"
- range_step	array	Returns minimum/maximum/step values of a parameter
- id	string	Returns an ID Value: "dimmer"
- min	integer	Returns a minimum value of a parameter
- max	integer	Returns a maximum value of a parameter
- step	integer	Returns a step value of a parameter
- bluetooth	object	Returns a information related to Bluetooth
- update_cancelable	boolean	Returns a whether updating can be canceled and connected to the device during Bluetooth (Sink) device list update
- speaker_settings	object	Reserved
- ymap_list	string array	Reserved
- web_control_url	string	Reserved
- speaker_pattern_num	integer	Returns the number of patterns that can be selected with the speaker setting function This parameter does not exist in models where speaker setting function is invalid
zone	array	Returns Zone related information
- id	string	Returns Zone ID. Refer to " All ID List " for details
- zone_b	boolean	Returns whether the target Zone is Zone B or not. Valid only when Zone ID is "zone2"
- func_list	string array	Returns a list of valid functions Values: "power" / "sleep" / "volume" / "mute" / "sound_program" / "surround_3d" / "direct" / "pure_direct" / "enhancer" / "tone_control" / "equalizer" / "balance" / "dialogue_level" / "dialogue_lift" / "clear_voice" / "subwoofer_volume" / "bass_extension" / "signal_info" / "prepare_input_change" / "link_control" / "link_audio_delay" / "link_audio_quality" / "scene" / "contents_display" / "cursor" / "menu" / "actual_volume" / "audio_select" / "surr_decoder_type"
- input_list	string array	Returns a list of selectable Input IDs Refer to " All ID List " for details
- sound_program_list	string array	Returns a list of selectable Sound Program IDs Refer to " All ID List " for details
- surr_decoder_type_list	string array	Returns a list of selectable Surround Decoder Types Values: "toggle" / "auto" / "dolby_pl" / "dolby_pl2x_movie" / "dolby_pl2x_music" / "dolby_pl2x_game" / "dolby_surround" / "dts_neural_x" / "dts_neo6_cinema" / "dts_neo6_music"
- tone_control_mode_list	string array	Returns selectable settings of Tone Control Mode. If there's no list of this, it's fixed to "manual" Values: "manual" / "auto" / "bypass"
- equalizer_mode_list	string array	Returns selectable settings of Equalizer Mode. If there's not list of this, it's fixed to "manual"