

CabinetSense Wiki


- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)
 - [CabinetSense Menu](#)
 - [CNC Menu](#)
 - [Component Menu](#)
 - [Document Menu](#)
 - [Help Menu](#)
 - [Profiles Menu](#)
 - [Scene Menu](#)
- [Component Layers](#)
- [Delete Construction Lines](#)
- [Face Me](#)
- [Toggle 3D Mode](#)
- [Toggle Door Layer](#)
- [Toggle Drawer Layer](#)
- [Toggle Scene Management](#)
- [Toolbars](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

[CabinetSense Wiki](#)

Toggle 3D Mode

Switches camera view between Perspective and Parallel Projection Mode

... **Perspective** ...



... Parallel Projection ...

