

Search this site

Embedded Files

Skip to main content

Skip to navigation

# CabinetSense Wiki

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)
  - [CabinetSense Menu](#)
  - [CNC Menu](#)
  - [Component Menu](#)
  - [Align](#)
  - [Apply Construction Profile](#)
  - [Change Door/Drawer Front/Panels](#)
  - [Change Height](#)
  - [Change Palette](#)
  - [Change Reveals](#)
  - [Choose New Drawer System](#)
  - [Choose New Handle](#)
  - [Component Options](#)
  - [Create Connector](#)
  - [Equalize Door and Drawer Front Heights](#)
  - [Fill](#)
  - [Hide/Unhide](#)
  - [Horizontal Cabinet Openings](#)
  - [Make Unique](#)
  - [Private Layer](#)
  - [Reconnect](#)
  - [Redraw](#)
  - [Resize](#)
  - [Toggle Closet Backs](#)
  - [Toggle Door Opening](#)
  - [Toggle Number of Doors](#)
  - [Transform](#)
  - [Vertical Cabinet Openings](#)
- [Document Menu](#)
- [Help Menu](#)
- [Profiles Menu](#)
- [Scene Menu](#)
- [Toolbars](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)

- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)


## [CabinetSense Wiki](#)

### Change Palette

The Change Palette dialog allows you to change the material palette for all components selected.

Usage:

- Multiple Components



All selected components will have their material palette changed to the one entered in the dialog.

NOTE: any container cabinets inside a cabinet will also have their material palette changed if their cabinet type matches.

- All material palettes use the naming convention of: Palette<palette name>
- You would enter the name of "Default" for the palette named PaletteDefault
- The material palette must be in the model for the colors of the palette to be displayed.

Page updated

[Report abuse](#)