


CabinetSense Wiki


- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
 - [Bifold Doors - Graphical Only](#)
 - [Combined Components](#)
 - [Placing Cutters](#)
 - [Pullout Drawer](#)
 - [Using Hidden Walls](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)


[CabinetSense Wiki](#)




You only need to change a couple of drawer properties to turn a regular drawer into a pullout.


- Add a drawer in the bottom opening.






- Change the drawer properties






- Override the drawer box height.



- If you're putting the pullout behind a door, add a spacer to give you room to get past the door:



- Add your door and you're done.

Page updated

Report abuse