


CabinetSense Wiki

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)
 - [CabinetSense Menu](#)
 - [CNC Menu](#)
 - [Component Menu](#)
 - [Document Menu](#)
 - [Help Menu](#)
 - [Profiles Menu](#)
 - [Open Profile](#)
 - [Outline Profile Parts](#)
 - [Profile Rendering](#)
 - [Save Profile](#)
 - [Upload Profiles \(CNC only\)](#)
 - [Scene Menu](#)
 - [Toolbars](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

[CabinetSense Wiki](#)

Save Profile

After you have assigned an outside profile and a panel profile, the Save option will become active. After selecting Save, a dialog will appear allowing you to enter a name for your profile. If the name already exists, you will be prompted to overwrite it.



NOTE: For CNC Customers, profiles are stored in the machining database while for non-cnc clients, CabinetSense will store it in a folder of your choosing.