

CabinetSense Wiki

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)

[CabinetSense Menu](#)

- [Dashboard](#)
- [Preferences](#)
- [Upgrade Library](#)
- [Upgrade Model](#)
- [Verify Model Integrity](#)
- [CNC Menu](#)
- [Component Menu](#)
- [Document Menu](#)
- [Help Menu](#)
- [Profiles Menu](#)
- [Scene Menu](#)
- [Toolbars](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

[CabinetSense Wiki](#)

Verify Model Integrity

CabinetSense will validate the selected component(s) and display any item messages that you need to review. If you do not have any components selected, all model components are reviewed.

You can change the level of checking that you would like to use by altering the setting in the [Preferences](#).