

Search this site

Embedded Files

Skip to main content

Skip to navigation

CabinetSense Wiki

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
 - [5-Piece Panel](#)
 - [Alignment](#)
 - [Banding](#)
 - [Cope and Stick](#)
 - [Faceframe Overlap](#)
 - [Grain Direction](#)
 - [Handle and Knobs](#)
 - [Insets](#)
 - [Joinery](#)
 - [Machining](#)
 - [Material](#)
 - [Other](#)
 - [Reveals](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

[CabinetSense Wiki](#)

Insets

Most CabinetSense parts will expose a number of inset properties and the number of insets will vary from part to part:

Grain Direction	Width (X)
	----- Inset -----
Back	0 mm
Front	0 mm
Left	0 mm
Right	0 mm
	----- Joinery -----

The insets are special in that they do not carry (or infer) any rules. CabinetSense applies the insets to the applicable parts whether they actually make any sense or not. They are typically used when you can't get CabinetSense to do what you want. You can usually force the part to do what you want using the insets.

[Page updated](#)

[Report abuse](#)