

BASTL INSTRUMENTS

60 KNOBS v1.5

FM FREQ

FM FREQ

COARSE

COARSE

COARSE

COARSE

COARSE

FM AMOUNT

FM AMOUNT

FM AMOUNT

OSC/NOISE

ATTACK

CLOSE HH DECAY

DECAY

DECAY

DECAY

DECAY

DECAY

OPEN HH DECAY

MODULATION

MODULATION

MODULATION

MODULATION

SLOPE

SLOPE

MOD DECAY

FILTER FREQ

FILTER FREQ

FILTER FREQ

FILTER FREQ

FILTER FREQ

DISTORTION

RESONANCE

RESONANCE

RESONANCE

RESONANCE

RESONANCE

DECIMATION

DECIMATION

DECIMATION

DECIMATION

DECIMATION

DECIMATION

VOLUME

VOLUME

VOLUME

VOLUME

VOLUME

VOLUME

LFO SYNC

LFO SYNC

LFO SYNC

LFO SYNC

LFO SYNC

LFO SYNC

LFO AMOUNT

LFO AMOUNT

LFO AMOUNT

LFO AMOUNT

LFO AMOUNT

LFO AMOUNT

KICK

TOM

TOM

SNARE

CYMBAL

HIHAT

- 10
- 9
- 8
- 7
- 6
- 5
- 4
- 3
- 2
- 1

FUNCTION LIST:

SET MIDI CHANNEL
HOLD **FN** + TWEAK **MIDI CH** KNOB

RECALL PRESET
HOLD **FN** + TWEAK **PRESET** KNOB

MIDI DUMP KNOB POSITION
DOUBLE-CLICK **FN** BUTTON.

MIDI CH

PRESET

FN

OFF/ON

IN

MIDI

OUT

POWER

COLLECTIVELY DEVELOPED BY THE BASTL COMMUNITY