

VOR or TACAN RWY 15
MARTIN STATE (MTN)

MISSED APPROACH: Climbing right turn to 2500 on BAL VORTAC R-068 and BAL 11 DME Arc clockwise to BOAST INT/BAL 11 DME and hold.

MISSED APPROACH: Climbing right turn to 2500 on BAL VORTAC R-068 and BAL 11 DME Arc clockwise to BOAST INT/BAL 11 DME and hold.

1549 Δ

(IAF) SLOAF
BAL 14.7

2600
BAL 14.7 Arc

1549 Δ

R-334

Δ 1464

(IF) CUMBE
BAL 14.7

R-021

1289 Δ

1800
BAL 14.7 Arc

588 Δ

GOVES
BAL 14.7

Δ 744

342 \pm Δ

ZOVAP
BAL 14.7

220 \pm Δ

167 \pm Δ

R-039

333 Δ

R-047

Δ 676

363 Δ

R-068

R-108

BOAST INT
BAL 11

224 Δ

R-060

BAL 11 Arc

288°

108°

R-055

R-4001A

401

R-4001C

R-4001B

BALTIMORE
115.1 BAL Chan 98

MSA BAL 25 NM

BALTIMORE, MARYLAND 39°20'N-76°25'W MARTIN STATE (MTN)
 Orig-D 17JUN21 VOR or TACAN RWY 15