

1 Kinematics

$$M_{RB}\dot{\boldsymbol{\nu}} + M_A\dot{\boldsymbol{\nu}}_r + \mathbf{C}_A(\boldsymbol{\nu})\boldsymbol{\nu} + \mathbf{C}_{RB}(\boldsymbol{\nu}_r)\boldsymbol{\nu}_r + \mathbf{D}(\boldsymbol{\nu}_r)\boldsymbol{\nu}_r = \boldsymbol{\tau} + \mathbf{w}(t) \quad (1)$$

$$\dot{\boldsymbol{\eta}} = \mathbf{J}(\boldsymbol{\eta})\boldsymbol{\nu} \quad (2)$$

$$\boldsymbol{\tau} = \boldsymbol{\tau}_{control} \quad (3)$$

2 Thruster model

$$\boldsymbol{\tau}_{control} = \begin{bmatrix} \boldsymbol{\tau}_{control,linear} \\ \boldsymbol{\tau}_{control,torque} \end{bmatrix} \quad (4)$$

Each propeller can rotate with an angle ξ_p . The thrust of each propeller can be describe as a vector by spilting it into components that align with the ship coordinate frame

$$t_p = T_{nn}n_p^2 + T_{nv}V_A n_p \quad (5)$$

$$\mathbf{T}_p = \begin{bmatrix} \cos(\xi_p) \\ \sin(\xi_p) \\ 0 \end{bmatrix} t_p \quad (6)$$

where t_p is the magnitude of the thrust and \mathbf{T}_p is the thrust vector. The linear control force is found as the sum of forces from each propeller p.

$$\boldsymbol{\tau}_{control,linear} = \sum^P \mathbf{T}_p \quad (7)$$

$$\boldsymbol{\tau}_{control,torque} = \sum^P \mathbf{r}_p \times \mathbf{T}_p = \sum^P S(\mathbf{r}_p)\mathbf{T}_p \quad (8)$$

where \mathbf{r}_p is the position vector of thruster p and $S(\mathbf{r}_p)$ is the skew-symetric matrix of vector \mathbf{r}_p .

In the case of two propellers we have

$$\boldsymbol{\tau}_{control} = \begin{bmatrix} I & I \\ S(\mathbf{r}_1) & S(\mathbf{r}_2) \end{bmatrix} \begin{bmatrix} \mathbf{T}_1 \\ \mathbf{T}_2 \end{bmatrix} \quad (9)$$