

Installation Guideline

Literature Part # MNL453

Proper SD Card Removal

SD Card Part Numbers:

32GB DV452, 64GB DV453, 128GB DV454, 256GB DV455

Estimated Installation Time – 3-5 Minutes

Difficulty Level - Easy

SD CARDS ARE SPECIFIC TO EACH RECORDER! DO NOT SWAP SD CARDS TO A DIFFERENT VEHICLE!

Removing the recorder from the bracket without powering the unit completely off will result in the following:

- Corrupted video files
- Corrupted SD Card
- Shorting or damaging the camera

Carefully follow the instructions below for the proper handling of your SD Card.



Turn the vehicle off.
The screen will dim
when in parking mode



Press and hold the
driver event
button



Release after you
see "SHUT" on the
display



Unlock the 2 locks
on both sides of the
recorder



(1) Swing the recorder
from the bottom upwards
until resistance is felt, (2)
then push up

Reverse procedure to reinstall
SD Card

PLEASE NOTE

The recorder is completely powered down 5
seconds after the screen goes black



Remove the card by
pushing down into the
slot. The card will pop
up

