

## Front Bumper (76.22.49)

### Removal

- 1 . Remove 6 screws and remove front grille.
- 2 . Remove 4 through bolts securing front bumper to chassis longitudinals.



- 3 . Remove front bumper.

### Installation

- 1 . Instal front bumper to chassis longitudinals and secure with bolts.
- 2 . Instal front grille and secure with screws.