



Glass panel replacement diagrams



LEVEL 03 PLAN

- ④ Transport Glass Manipulator to bridge level in elevator.
- ⑤ Use chain hoist and attachment by Glazing Contractor to lift unit to bridge level through the floor access door.



EAST-WEST SECTION

- ⑤ Use chain hoist and attachment by Glazing Contractor to lift unit to bridge level through the floor access door.
- ⑥ Close and secure floor access door. Use dolly and hoist to reposition glazing into horizontal orientation. Removable wall panel at station roof level provided for additional access.