



PROCEDURE
FROM
MAINTENANCE
TO IN SERVICE.


KEY EXCHANGE
BOX
AT 66KV
SWITCHROOM




STEP
1




KEY EXCHANGE
BOX
AT 66KV
SWITCHROOM




STEP
2



KEY EXCHANGE
BOX
AT 66KV
SWITCHROOM



STEP
3



KEY EXCHANGE
BOX
AT 66KV
SWITCHROOM



STEP
4

