




Build the Small Clone circuit on this layout. The FET switching has been removed to use true bypass switching. Layout shown with depth mod applied, see 'schematic for depth switch' for stock wiring. Pads A, B, C, D, E are for the stereo mod. Off board components except for the potentiometers are not shown on the layout. Trademarks are property of their owners.



LAYOUT



READY TO TRANSFER



Schematic
(Depth pot mod included)

Layout and presentation by Francisco Peña 2001-2005®.
All rights reserved. Authorization for personal use only,
any commercial use is forbidden.
Permission for posting/serving limited to
<http://www.tonepad.com>
Permission refused for posting from other sites.