

Defining a window in time domain

Introduction

In this tutorial you will learn how to obtain a window in time domain. A window can be applied to data, either time series (data window) or covariance functions (lag window), before computing their DTFT.

Different windows provide different trade-offs between resolution and leakage obtained in the frequency domain. To check these trade-offs, see tutorial '[getting_DTFT_from_window](#)'.

Tutorial

First of all, add mVARbox to path, set the tutorial parameters.

```
setmVARboxPath
```

mVARbox path has been added to MATLAB path

```
clear
clc
close all

%%% Parameters
window_type = 'data_window';    % 'data_window' for time series
                                % 'lag_window' for covariance functions

N_window     = 30;              % number of elements
                                % must be even for data_window
                                % must be odd for lag_window

window_name_list = {'rectangular',...
                    'triangular',...
                    'Hann',...
                    'Hamming',...
                    'Nuttall',...
                    'Truncated_Gaussian',...
                    'Chebyshev'};

alpha_vector = linspace(1,5,5); % Values of alpha parameter
                                % for Truncated Gaussian window


%%% Plot parameters
font_size     = 18;
line_width    = 2;
```

Initialise a window object.

```
window0 = initialise_window('type',window_type,...  
                           'N',N_window);
```

Get a triangular window and plot it. For a list of available window names, see function `initialise_window`.

```
window_triangular          = window0;  
window_triangular.name     = 'triangular';  
  
window_triangular = get_window(window_triangular);  
  
figure  
  
x = window_triangular.x_values;  
y = window_triangular.y_values;  
plot(x,y,'.-','LineWidth',line_width)  
xlim([x(1) x(end)])  
grid on
```



Get all the windows included in `window_name_list`, and plot them.

```
figure
```

```

for ii = 1:numel(window_name_list)

    window_local      = window0;
    window_local.name = window_name_list{ii};
    window_local      = get_window(window_local);

    x = window_local.x_values;
    y = window_local.y_values;
    plot(x,y,'.-','LineWidth',line_width)

    hold on

end


```

Warning: Using default parameters for window Nuttall
Warning: Using default parameters for window Truncated_Gaussian
Warning: Using default parameters for window Chebyshev

```

xlim([x(1) x(end)])
window_name_list_fancy = strrep(window_name_list,'_',' ');
legend(window_name_list_fancy,'Interpreter','latex','location','bestoutside')
grid on
set(gca,'fontsize',font_size)

```



Note the obtained warnings. This is because, for some windows, additional parameters are required. If not provided, default values are internally taken from function `fun_default_values`.

For example, Truncated Gaussian depends on parameter α . Get different Truncated Gaussian windows for different parameter values.

```
figure

for jj = 1:numel(alpha_vector)

    % define the parameter value
    alpha = alpha_vector(jj);

    % define the substructure 'y_parameters' for window object
    y_parameters.alpha = alpha;

    % initialise window with substructure y_parameters
    % (alternatively, just plug 'y_parameters' into an existing window)
    window_alpha = initialise_window('type',window_type,...
                                    'name','Truncated_Gaussian',...
                                    'N',N_window,...
                                    'y_parameters',y_parameters);


    window_alpha      = get_window(window_alpha);

    x = window_alpha.x_values;
    y = window_alpha.y_values;
    plot(x,y,'.-','LineWidth',line_width)

    hold on

end

title('Truncated Gaussian window','Interpreter','latex')
xlim([x(1) x(end)])
alpha_vector_fancy = strcat('$\alpha =',sprintfc('%.2f',alpha_vector));
alpha_vector_fancy = strcat(alpha_vector_fancy,'$');
legend(alpha_vector_fancy , 'Interpreter','latex','location','bestoutside')
grid on
set(gca,'fontsize',font_size)
```



Remarks

- Note that windows applied to time series (data windows) range from $x[0]$ to $x[N - 1]$, where N is the data length, while windows applied to covariance functions range from $x[-M]$ to $x[M]$, where M is the maximum lag of the covariance function. Thus, in the latter case it holds that $N = 2 \cdot M + 1$. You can explore both window types by changing the parameter `window_type`.