



SIDs RWY 09  
Northern Departures

PROBE1F: Track direct VOX FL010 then heading 302 to DINER FL020 and after heading 273 to PROBE FL030.  
ROMENS1F: Track direct VOX FL010 then turn heading 340 to ROMENS FL030.  
CAMEL1F: Track Direct VOX FL010 then turn heading 080 to CAMEL at FL030.