


CineMoco controller automatic update scripts

First, please navigate to:

<http://www.ftdichip.com/Drivers/VCP.htm>

... And install the appropriate VCP driver so your computer can talk to the controller.

And then...



```
C:\WINDOWS\system32\cmd.exe
Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows\v23.hex
C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows>echo C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows\v23.hex
C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows\v23.hex
C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows>set mydude=C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows\bin\avrdude
C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows>cscript C:\Users\Eric\Dropbox\Cloned\CineMoco\CineMocoUpdate\Windows\myvbscript.vbs
Microsoft (R) Windows Script Host Version 5.8
Copyright (C) Microsoft Corporation. All rights reserved.

Hardware and libraries installed successfully.
=====
COM3 = \Device\Winachsf0
COM5 = \Device\VCP0
which COM port above looks like: COMxx = \Device\VCP0?
For example, please enter 5 if you see COM5 = \Device\VCP0
NOTE: If you don't see this go to http://www.ftdichip.com/Drivers/VCP.htm and download the appropriate driver.
5
```