





Size: A4	Date:
KiCad E.D.A. kicad 6.0.10-86aedd382b-118-ubuntu20.04.1	

Rev:  
Id: 4/12





Sheet: /Tayloe Detector/  
File: taylor-detector.kicad\_sch


**Title:**

Size: A4  
KiCad E.D.A. kicad 6.0.10-86aedd382b-118-ubuntu20.04.1

Date:

**Rev:**


Id: 6/12



A blank sheet of paper with a grid pattern. The grid has columns labeled 1 through 6 at the top and bottom, and rows labeled A, B, C, and D on the left and right sides. In the center of the grid, there are two small, faint, light blue rectangular shapes. One shape is slightly above and to the left of the other. Both shapes have a thin black border and contain some very faint, illegible text. At the bottom right corner, there is a white rectangular box containing a title block.

Sheet: /Local Oscillator/ File: local-oscillator.kicad_sch	
<b>Title:</b>	
Size: A4	Date:
KiCad E.D.A. kicad 6.0.10-86aedd382b-118-ubuntu20.04.1	Id: 8/12






Sheet: /Audio Switch/  
File: audio-switch.kicad\_sch


**Title:**

Size: A4  
KiCad E.D.A. kicad 6.0.10-86aedd382b-118-ubuntu20.04.1

Date:

Rev:  
Id: 9/12





Sheet: /MIC/ File: mic.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad 6.0.10-86aedd382b-118-ubuntu20.04.1		Id: 11/12

