



NOTE:

- Filter caps and slew cap(s) can be chosen according to taste.
- The slew caps C1 and C2 can be replaced with one bipolar 470uF capacitor.
- With both filters off it becomes more of a VCA, no filtering.
- R3 is there basically because RV1 is way too big (no effect on upper half of pot sweep).
- R2 is there because of a dead spot at the lower end of the sweep. Could use a resistor of 100-150 ohm instead.
- Using another optocoupler ("Vactrol") could change the characteristics of the circuit (try!).
- It is also possible to make your own optocoupler with an LDR, a LED, and shrink tube.

Sheet: /

File: passive_aggressive_1.sch

Title: Passive Aggressive Low Pass Gate

Size: A4 Date: 2018-06-01

KiCad E.D.A. kicad 4.0.7

Rev: A

Id: 1/1