





GPS With FC





BOTTOM FRONT ↑



TOP FRONT ↑



* Press the middle button of the
osd menu board to enter the menu
* packing does not contain an OSD menu board



Sheet: /
File: chimeraConn.kicad_sch

Title:			
Size: A4	Date:	Rev:	
KiCad E.D.A. 9.0.0		Id: 1/1	