





GPS With FC






BOTTOM FRONT ↑



TOP FRONT ↑





* Press the middle button of the
osd menu board to enter the menu
* packing does not contain an OSD menu board



Foxeer M10Q-120 compass

M1
SpeedyBee_Nano_2.4G

M2
ANT Lite



FC1
F405_4S_20A_Toothpick_Brushless_Flight_Controller_V5_BLHeli_S

M4
Foxeer Reaper Nano V2 VTx 5.8G 72CH 350mW Tramp

Sheet: /
File: chimeraConn.kicad_sch

Title:

Size: A4

Date:

Rev:

KiCad E.D.A. 9.0.0

Id: 1/1