



TOP 6 BOARD VIEW



10 / GP105 to SD CARD CS
11 / GP1018 to SD CARD SCK
12 / GP1219 to SD CARD SDO/MISO
18 / GP1023 to SD CARD SDI/MOSI



I2C DEVICES (Bottom)

